



DESIGN METHODOLOGY

RatedPower



pvDesign

by RatedPower

Index

- 1. Glossary 5
- 2. Purpose..... 6
- 3. Account Preferences 7
- 4. Projects 8
- 5. Design Process 12
 - 5.1. Preview of the design 12
 - 5.2. Location 17
 - 5.2.1. Site 17
 - 5.2.2. Topography 23
 - 5.2.3. Meteo data 25
 - 5.3. Equipment 28
 - 5.3.1. PV Module 29
 - 5.3.2. Inverter 29
 - 5.3.3. Structure 32
 - 5.3.3.1. Type of Structure 32
 - 5.3.3.2. Create a new Structure 33
 - 5.3.3.3. Layout Configuration 34
 - 5.3.3.4. Mounting System 38
 - 5.3.3.4.1. Trackers 38
 - 5.3.3.4.2. Fixed structures 39
 - 5.3.3.4.3. E-W Structure 41
 - 5.3.4. Power Station 42
 - 5.3.4.1. Transformer configuration 45
 - 5.3.4.2. Transformer losses 46
- 5.4. Layout Tab 47
 - 5.4.1. LV grouping 48
 - 5.4.2. Power Requirements 49
 - 5.4.3. Distances 51
 - 5.4.4. Layout configuration..... 53

- 5.4.4.1. Roads Layout..... 53
- 5.4.4.2. Structure alignment..... 55
- 5.4.4.3. Rotation 55
- 5.4.5. Power station location 56
- 5.4.6. Setbacks..... 57
- 5.5. Topography 62
 - 5.5.1. Topography limitation tool..... 62
 - 5.5.2. Earthworks 68
 - 5.5.3. Preview 69
- 5.6. Grid Point..... 70
 - 5.6.1. Electrical standards..... 70
 - 5.6.2. Connection Type 70
 - 5.6.3. Overhead Line 73
 - 5.6.4. Losses 76
 - 5.6.5. Grid requirements 76
- 5.7. Electrical..... 81
 - 5.7.1. Solar field..... 81
 - 5.7.1.1. String positioning within a structure 81
 - 5.7.1.2. Configuration Type 81
 - 5.7.1.3. Harness..... 83
 - 5.7.2. Cable Sizing 84
 - 5.7.2.1. Electrical Standard 84
 - 5.7.2.2. Maximum voltage drops 85
 - 5.7.2.3. Cables 85
 - 5.7.2.4. Cable sizing parameter 86
- 5.8. BESS 87
 - 5.8.1. AC coupled BESS 87
 - 5.8.1.1. Power Conversion System..... 87
 - 5.8.1.2 Battery container 88
 - 5.8.1.3. BESS requirements 88
 - 5.8.1.4. BESS layout..... 89

5.8.2. DC coupled BESS.....	91
5.8.2.1. Power Conversion System.....	92
5.8.2.2 Battery container	92
5.8.2.3. BESS requirements	92
5.8.2.4. BESS layout.....	93
5.9. Energy	95
5.9.1. Simulation.....	95
5.9.2. Horizon	95
5.9.3. Surface Albedo	95
5.9.4. PV Module Losses	97
5.9.5. PV Plant Losses	99
5.9.6. Advanced Configuration (Energy Tab).....	99
5.10. Financial Tab.....	101
5.11. Settings tab.....	109
6. Simulation procedure	110
6.1. Batch design tool	110
7. Simulation results	114
8. Documentation	117
8.1. Documents	118
8.1.1. Design Report.....	118
8.1.2. Energy Yield Report.....	119
8.1.3. Interconnection Facility Report.....	120
8.1.4. BESS Design Report	121
8.1.5. Overhead Line Report	122
8.2. Spreadsheets.....	123
8.2.1. Project Sheet	123
8.2.2. Bill of Quantities.....	124
8.2.3. Financial Analysis	125
8.2.4. Energy Yield Results.....	126
8.2.5. Listing of Cables	127
8.2.6. Listing of Posts	128

- 8.2.7. Terrain XYZ 129
- 8.2.8. Power flow model 129
- 8.3. Drawings..... 130
 - 8.3.1. General Layout 130
 - 8.3.2. Layout 3D..... 131
 - 8.3.3. 3D scene (PVC) 131
 - 8.3.4. MV Single Line Diagram 132
 - 8.3.5. LV Single Line Diagram 133
 - 8.3.6. MV-LV Single Line Diagrams..... 136
 - 8.3.7. Topography Analysis (terrain slopes) 137
 - 8.3.8. Structure Profiles 138
 - 8.3.9. Interconnection Facility SLD 139
 - 8.3.10. Interconnection Facility Layout 140
 - 8.3.11. BESS General Layout 141
 - 8.3.12. BESS MV-LV Single Line Diagram 142
 - 8.3.13. Overhead line layout 143

1. Glossary

AC: Alternating Current.

DC: Direct Current.

BOQ: Bill of Quantities.

GCR: Ground Cover Ratio.

LV: Low Voltage.

MV: Medium Voltage.

HV: High Voltage.

PV: Photovoltaic.

TMY: Typical Meteorological Year.

PS: Power Station.

L2: Second Level

MPPT: Maximum Power Point Tracking.

KML: Keyhole Markup Language

KMZ: Keyhole Markup Language Zipped

2. Purpose

The purpose of the **RatedPower** platform is to help in the design and development of utility-scale photovoltaic solar projects during the phases of feasibility, conceptual design, basic design, and request for proposal.

The main advantages of **RatedPower** are the optimization of the design, the short time it takes, and the easy generation of the documents and drawings needed for requesting the proposal. This can be done following these steps:

- Step 1 - **Create a project** in which the user will create different designs.
- Step 2 - **Create a design** in which the user will upload or create their site and choose a configuration.
 - Create or upload the site: define the plot areas of the plant using Google Earth (KML or KMZ file) and upload them into **RatedPower** or create a site directly inside RatedPower's interactive map.
 - Check the topography and meteorological data of the plot area.
 - Customize the design: Select the equipment, layout configuration, perform topography analysis, choose the grid connection, add a battery energy storage system, and customize energy and costs criteria. For more information, please refer to [chapter 5- Design Process](#)
- Step 3 - **Check** the energy results and layout corresponding to the civil, electrical, and energy configuration. If the user has generated more than one design, they can also use the comparison tool to analyze the different results.
- Step 4 - **Download the documents, spreadsheets, and drawings** of the project proposal. For more information, please refer to [chapter 8](#).

3. Account Preferences

RatedPower allows users to change the preferred language, unit system, and temperature units of the program's interface.

Users can choose between the international metric system and the imperial system. As for temperature, two options are available: degrees Celsius (°C) and degrees Fahrenheit (°F).

These options can be changed by accessing the account preferences on the bottom left corner of the software as shown in Figure 3.1.




Figure 3.1. Account information.

And then selecting the preferred option for each as shown in Figure 3.2.


A light gray rectangular form titled 'Language and metrics preferences'. It contains three rows of settings: 'Language' with a dropdown menu showing 'English' and a downward arrow; 'Unit System' with two radio buttons, 'Metric System' (selected) and 'Imperial'; and 'Temperature Units' with two radio buttons, 'Celsius' (selected) and 'Fahrenheit'.

Figure 3.2. Language, unit system and temperature units.

4. Projects

In **RatedPower**, every time the user logs in, he will see the project's tab, where he will be able to see all the projects he or his team have created.

Projects						+ New Project	
Projects		Favorites		Archived		Q Search	
Name ↓							Date ↓
BESS Webinar	Altair Support RatedPower	-	-				October 23, 2023
Malaysia	Arif Ibrahimov	10 designs	Malaysia, Selangor, Banting				October 11, 2023
Demo France	Helene Laurent	12 designs	France, Nouvelle-Aquitaine, Villefranque				October 09, 2023
Kendall County	Hillary Thomas	1 Design	United States, Wisconsin, Melrose				October 06, 2023
Demo Italia	Matteo Menazzi	13 designs	Italy, Apulia, Spinazzola				September 25, 2023
Demo Romania	Victor Domingo Santalices	7 designs	Romania, Bucuresti, Bucuresti				September 15, 2023
Demo croatia	Faten Driss	15 designs	Croatia, Zagreb County, Nova Kapela				September 15, 2023

Figure 4.1. Projects tab.

A project is understood as a location in which infinite designs can be simulated. Different sites can be added to the same project as long as their center point is within a radius of 5 km from the project origin. The project origin is set through the first site ever uploaded.

Project Definition




Figure 4.2. Valid area definitions inside the project radius.

Once the user has one or more projects created, he can use the different organizational aspects of the software. For example, he can select to view his projects in three ways. The user can select the list, list/map or simply map view, as shown inside the red box in Figure 4.3. For the list view, he can organize his projects by name or date. Besides that, he can also use other features such as selecting his favorite projects, archiving them, or filtering them based on different parameters such as the number of designs, country and creator.



Figure 4.3. Project organization aspects.

Once the user opens any project, he'll be able to see the existing designs if there are any created. He can enable design details to see information such as the power, the energy, the meteorological data and so on. The filter option allows the user to filter by meteo source, type of design (single or multiple), creator and score.




Figure 4.4. Design organization aspects.

Users can select 2 to 24 designs to compare them, as shown in Figure 4.5.




Figure 4.5. RatedPower's comparison tool.

Once inside the comparison tool, the user can select the parameters that he wants to compare through the 'Filters' menu. The user can add other designs to the comparison ('+' button) or remove them (clicking on the 'x' above each column). The comparison can be seen in data tables or charts.




Figure 4.6. Inside RatedPower's comparison tool.

If further comparisons are needed, the user has the option to export the data tables and charts in xlsx.




Figure 4.7. Export option inside the comparison tool


5. Design Process

5.1. Preview of the design

The map in the middle of the screen allows for a preliminary visualization of the layout before generating the design. This map allows users to see how their modifications for different parameters affect the layout and the achieved power of the PV plant.

The Design Process is divided into different sections:

In the middle of the top bar is the 'Run Design' button (shown in purple in Figure 5.1.1), which allows the user to apply his changes to his design and update all the other information displayed on the page. In blue he will also find the different views of the design. In the same banner the user can download the documentation (green in Figure 5.1.1) and save his design (Folders) (pink in Figure 5.1.1).



The screenshot displays the pvDesign software interface for a project named 'helene-0' in Biarritz, France. The central map shows a satellite view with three PV array polygons labeled 'AA-Polygon1', 'AA-Polygon2', and 'AA-Polygon3'. The interface includes a top navigation bar with buttons for 'Run design', 'Preview map', 'Overview', and '3D Map'. A left sidebar contains navigation options like 'Location', 'Site', 'Topography', and 'Meteo data'. A right sidebar shows a 'Layers' panel and a 'helene-0' summary panel with power and energy statistics. At the bottom right, a 'History of designs' list shows previous design iterations.

helene-0		
Power	Rated Power	Peak Power
	14.664 MWac	17.446 MWdc
	DC/AC Ratio	1.190
Energy	Total Unused ...	Maximum Pe...
	0 Wdc	17.446 MWdc
	Energy	Specific Prod... Performance ...
	22.551 GWh	1292.6kWh/... 83.4%
Financial	Show values per area	

History of designs		
<input type="checkbox"/>	201. Biarritz_9_10	15:32 - 2023-12-28 - Helene Laurent
<input type="checkbox"/>	200. Biarritz_9_10_10	15:30 - 2023-12-28 - Helene Laurent
<input type="checkbox"/>	199. Biarritz_9_10_9	15:30 - 2023-12-28 - Helene Laurent
<input type="checkbox"/>	198. Biarritz_9_10_8	15:30 - 2023-12-28 - Helene Laurent
<input type="checkbox"/>	197. Biarritz_9_10_7	15:30 - 2023-12-28 - Helene Laurent

Figure 5.1.1. Layout preview map

The available maps in the Design Process are:

1) Preview map

As shown in figure 5.1.1, the first view that the user can select is the Preview map. In this view, the structures are shown following a color code legend:

- **Light blue**: Installed structures.
- **Dark red**: Uninstalled structures due to electrical configuration.
- **Orange**: Installed structures with earthworks.
- **Light brown**: Earthworks platforms.
- **Light blue**: Uninstalled structures due to the lack of topography coverage.




Figure 5.1.2. Layers of the preview Map

2) Overview

The second view is the overview (Figure 5.1.3), which shows the structures in different shades of blue. Structures connected to the same power station are in the same shade of blue. This view also allows the user to see the main civil and electrical parts of the plant. These parts are detailed in the layers.



Figure 5.1.3. RatedPower's layout overview

3) 3D map




Figure 5.1.4. 3D map

Using the 3D map, the user will be able to see his PV plant in a 3D view. The structure will follow this color code legend:

- **In different shades of blue:** Structures that are connected to the same power station will be in the same shade of blue.
- **With a brown background:** Installed structures with earth works.

The main results are displayed on the top right side of the screen. Here, the user will find power, energy, financial, substation, and if a BESS or an OHL is included, BESS and OHL results.




Figure 5.1.5. Design results.

On the bottom right side, the user can view the history of designs created in the last 24 hours. Designs that are not saved within 24 hours will be deleted.




Figure 5.1.6. History of designs.

In the right corner, the user can always access our resources by clicking on the question mark button. Direct links to our Methodologies, knowledge base articles and more are available in the following list.




Figure 5.1.7 Support resources

5.2. Location

5.2.1. Site

To start defining a project, it is necessary to define the site where the PV plant will be built. For this purpose, the input information needed to develop the project is the following:

- **Available areas:** Area(s) to develop the PV project.
- **Access points:** Each available area must have a main street access point. Adding a secondary access point is also possible.
- **Substation area:** The area to carry out the substation.
- **MV-Switchgear:** is the point of the substation (ST) at which the medium voltage will arrive from the available areas.
- **Medium Voltage Delivery Point [optional]:** is within the Available Area (AA); it is the point to deliver energy from this specific area to the Substation (ST).
- **Restricted areas [optional]:** Area(s) where PV panels are not allowed to be installed. These area(s) could be restricted due to slopes, water bodies, rivers, electrical overhead lines, buildings, etc.
- **MV route [optional]:** path(s) that connects (via electrical cable) different available areas together, or from each available area to the substation.
- **Shortcuts [optional]:** user defined roads that connect with the automated roads. It's helpful if there's an existing road that the user would like to keep in the layout, even though the software automates them.
- **OHL/Gen-Tie [optional]:** overhead line; it's the path defined by the user that connects the plant substation via MV or HV cable, to the utility or other interconnection point.
- **Batteries area [optional]:** it's the area to develop AC-coupled battery energy storage system. It also requires an MV point to mark the delivery energy from this specific area to the Substation (ST).

RatedPower calculates the meteorological data, the elevation, and the slopes of the site.




Figure 5.2.1.1 Example of a site definition in Google Earth

In Figure 5.2.1, a project site is defined with the following elements:

- 2 AVAILABLE AREAS in dark blue
 - ACCESS POINTS: Each area has only one primary access AC. In Figure 5.2.1, the area on the right has a secondary access ACb.
- 1 RESTRICTED AREAS in red
- BATTERY AREA in yellow
- SUBSTATION AREA in purple
 - MV SWITCHGEARS: Point at which all the medium voltage cables coming from the available areas and battery, connect with the substation (in purple).
- MV ROUTE
- SHORTCUTS (ROAD ROUTE)
- OHL/Gen-Tie ROUTE

To define the project correctly, it is necessary to generate all the previous information in a Google Earth file and to upload it in Location->Site (both KML and KMZ formats are accepted). For more information on how to define a project site using Google Earth, check the following [knowledge base article](#).

It is also possible to create or modify a site directly in RatedPower using the [interactive site creation tool](#). This tool can be accessed by clicking the 'Create New Site' button.




Figure 5.2.1.2 Site definition options

These following requirements must be defined in every site:

- At least one available area (AA).
- A road access point (AC) inside each available area.
- A substation area (ST) or switching and breaking station (SBS).
- A medium voltage switchgear point (MV) inside the substation or SBS area.




Figure 5.2.1.3 Interactive site creation tool.

At the top left of Figure 5.1.1.3. A **search bar** is available for the user, where the location coordinates can be inserted. In order to draw his site, the user can use the following tools: the polygon tool, the placemark tool and the path tool.

By using the **polygon tool**, users can define the following areas: *available areas (AA), the substation (ST), switching and breaking station (SBS), restricted areas (RA), and the battery area (BA).*

The user has the option of defining these areas using the free-shape tool, the rectangular, or circular tool.




Figure 5.2.1.4 Polygon tool.

By using the **placemark tool**, the user can define the following points: *the road access points (AC), the secondary road access points (ACb), and the medium voltage points (MV).*




Figure 5.2.1.5 Placemark tool.

By using the **path tool**, he can define the following elements: *the MV routes, the shortcuts, and overhead lines (OHL).*




Figure 5.2.1.6 Path tool.

On the sidebar, the user can view all the defined elements. He can also select any element and delete it by clicking on the trashcan icon.




Figure 5.2.1.7 Side Bar.

Users can change the type of element within the same bracket. For instance, if an AA area is created, it can be switched into any other type of polygon (ST, RA, or BA in this case).




Figure 5.2.1.7 Elements type modifications.

Warnings will be displayed in the same section, if requirements are not met.

Once the site is completed, the user can either save it as a draft (default option when not all required elements are created) or as a new site that would allow him to start simulating. When saved as a draft, the user can continue working on the site at a later moment. He can also download the site in kml format by clicking on the "Download .kml" button.




Figure 5.2.1.8 Site saving's options.

If changes are required for the site, the user can always "Clone" the site.




Figure 5.2.1.9 Selected site options.

For more information on how to define a project site inside **RatedPower**, check the following [knowledge base article](#).

5.2.2. Topography

The topography of the PV plant is defined by Google Earth or uploaded by the user.

RatedPower generates a colored slopes map that can be accessed by pressing on the “See details” button as shown in Figure 5.2.2.1.




Figure 5.2.2.1. Topography box.

The slopes have been colored by default for the range of:

- Slopes less than 5%: green arrows.
- Slopes from 5% to 10%: orange arrows.
- Slopes from 10% to 15%: red arrows.
- Slopes above 15%: purple arrows.

However, it can be modified by using the slider on the right as shown in Figure 5.2.2.2.

Google Earth files of the site and of the custom slopes of the terrain can be downloaded. These files allow users to define more accurately their restricted areas. To do so, click on the “Download” button marked inside a blue box in Figure 5.2.2.2 and select the file to download and the format.




Figure 5.2.2.2. Slopes of the terrain.

NOTE: The topography is taken into account only for structure placement, not energy analysis. **RatedPower** considers the terrain to be flat when creating the final layout, which means that shading due to the terrain slopes is not taken into account.

RatedPower utilizes SRTM30 to get the topography details. SRTM30 is a near-global digital elevation model. It combines data from both the Shuttle Radar Topography Mission and the U.S. Geological Survey's GTOPO30 data set. It has a resolution of 30x30 meters.

Users can also opt to upload their own topography. This can be done by uploading a CSV file with the custom elevation data of the site. This data needs to be in XYZ format where "X" is the easting coordinate placed in the first column, "Y" is the northing coordinate placed in the second column, and "Z" is the elevation value in meters placed in the third column. The coordinates should belong to the same UTM zone as the project and should roughly cover the same area as that of the site. Maximum file size of 500 MB is permitted.

A similar excel sheet with the elevation data provided by Google Earth can be downloaded by pressing "CSV" as shown inside the blue box in Figure 5.2.2.2. This excel sheet also includes the exact UTM zone of the uploaded site.

5.2.3. Meteo data

Once the site is defined, in addition to the topography data, **RatedPower** also generates a Typical Meteorological Year based on the historical data of the NASA-SSE database, the NASA-Power database, and the PVGIS 5.2 database.

The **NASA SSE** solar resource website, sponsored by NASA's Applied Science Program, supports the investigation of climatological phenomena by providing publicly available climate data for the globe. This data includes long-term estimations of different meteorological variables.

The main features of the NASA SSE data source are:

- Source: Satellite
- Spatial Coverage: Global
- Spatial resolution: 1° x 1°, approximately (100 km x 100 km)
- Temporal resolution: Long-term, monthly, and daily
- Uncertainty: 6 % to 12 %

NASA POWER database has the same features as NASA SSE. Both have the same irradiation information but a different temperature curve.

The main features of the NASA POWER data source are:

- Source: Satellite
- Spatial Coverage: Global
- Spatial resolution: 1/2° x 2/3°

- Temporal resolution: 3-hourly, daily, monthly, and long-term

PVGIS has been in continuous development for more than 10 years at the European Commission Joint Research Center. The focus of PVGIS is research in solar resource assessment, photovoltaic (PV) performance studies, and the dissemination of knowledge and data about solar radiation and PV performance.

The latest version of PVGIS (PVGIS-5.2) has extended the capabilities of the system and improved the coverage of the meteorological database. PVGIS-5.2 uses PVGIS-SARAH-2, PVGIS-SARAH-1, PVGIS-ERA5 and PVGIS-NSRDB databases. The main features of the PVGIS-5.2 database are:

- Source: Satellite
- Spatial coverage: Worldwide
- Spatial resolution: site-dependent, with an average value of 4 km x 4 km
- Temporal resolution: hourly
- Uncertainty: site-dependent, $\pm 3\%$ to 10% on average

The solar irradiance data of PVGIS have been calculated using satellite data. There are four satellite databases available:

- **PVGIS-SARAH-2** is a database based on data provided by the EUMETSAT CM SAF. It uses the images of the METEOSAT geostationary satellites covering Europe, Africa and Asia. The temporal period is 2005 to 2020.
- **PVGIS-NSRDB** is a collaboration between PVGIS and the NREL (National Renewable Energy Laboratory), and it consists of the implementation of the NSRDB in PVGIS. The temporal period is from 2005 to 2015.
- **PVGIS-ERA5** is a reanalysis product from ECMWF, combining historical observations into global estimates using advanced modelling and data assimilation systems. It provides coverage in areas where there is no satellite data, such as some parts of South America, Australia, and Japan. The temporal period is 2005 to 2020.
- **PVGIS-SARAH-1** is a database based on a new algorithm developed by CM SAF. It provides coverage in Asia. The temporal is from 2005 to 2016.

Additionally, if the user has an API key for **SolarAnywhere**, **Solcast** or **Solargis** they can add it to use this meteo source in the designs. The key can be added in the "My company" page inside **RatedPower**, in the "Integrations" section.




Figure 5.2.3.1. API Integrations.

If the checkbox of "Load SolarAnywhere (or Solcast) data automatically for every new project" is selected, the meteorological data will be automatically generated in all projects. The data will be generated only once per project when there is at least one site uploaded.

If the checkbox is not selected, the data can be generated during the design process.

The monthly data from both NASA sources is automatically converted to hourly data by the software to calculate the energy production.

The Typical Meteorological Year (TMY) consists of a representative set of monthly average values of global solar radiation and temperature for a 1-year period. TMY is the most common data for describing the local solar climate.

The resulting TMY is for user information and is used to get the minimum and maximum temperature values of the site in order to define the range of modules per string estimated. It also allows the software to compute accurately the energy production for each hour for the whole lifetime of the PV plant.

In addition, it is possible to import a TMY in monthly, hourly and sub-hourly (15 min, 5 min and 1 min) values data in CSV format. This option allows the user to import their own meteorological data from databases like SolarGIS, Meteonorm, NREL TMY3, Vaisala, meteorological stations on-site, etc. Monthly data is automatically converted into hourly data by our software.




Figure 5.2.3.2 The minimum historical temperature of the site.

Additionally, **RatedPower** allows users to modify the minimum historical temperature of the site as shown in Figure 5.2.3.2. This value affects the range of the number of modules of strings.

5.3. Equipment

RatedPower has an extensive database of electrical equipment (PV modules, central and string inverters, and structures). However, we also give users the possibility to upload their own equipment to their own **private** database. Users can choose to upload their own PV modules or inverters, and create their own custom structures (trackers, fixed structures and East-West structures). A .pan file is needed for the PV modules, and a .ond file for the central and string inverters. For structures, users simply need to fill in the information regarding the dimensions and the configuration.

To do so, a user should go to the “Equipment” tab on the left-hand side as shown in the red box of Figure 5.3, choose if he is looking to upload a module or an inverter and upload his equipment using the upload button on the right-hand side as shown in the orange box of Figure 5.3.1.

Manufacturer	Model	Power [W]	Voltage [V]	Technology	Type	Uploaded by	Publication Date	Database	Show	View details
ET Solar	ET-M772BH545TW	545	1500	SI_MONO	Bifacial	Rated Power	October 27, 2023	Private	🔍	View details
Hanersun	HN21-66HT650W	650	1500	SI_MONO	Bifacial	Rated Power	October 20, 2023	Public	🔍	View details
Hanersun	HN21-66HT655W	655	1500	SI_MONO	Bifacial	Rated Power	October 20, 2023	Public	🔍	View details
Hanersun	HN18N-72HT585W	585	1500	SI_MONO	Bifacial	Rated Power	October 19, 2023	Public	🔍	View details
Hanersun	HN18N-72H585W	585	1500	SI_MONO	Monofacial	Rated Power	October 19, 2023	Public	🔍	View details

Figure 5.3.1 The Equipment tab.

In the “Settings” tab, the user can set default equipment per company and/or per project.

Company default equipment

Set some equipment as default in all your company's projects and recognize them with this icon.

Modules

Manufacturer	Model	Power [W]	Voltage [V]	Technology	Type	Uploaded by	Publication Date	Database	View details	Change
General	General610	610	1500	SI_MONO	Bifacial	Rated Power	December 05, 2022	Public	View details	Change

Inverters

Central Inverter | String Inverter

Manufacturer	Model	Pmax [kVA]	Phom [kVA]	Max Voltage [V]	Efficiency [%]	Uploaded by	Publication Date	Database	View details	Change
Generic (default)	Generic 2310	2310	2310	1500	98.72	Rated Power	February 21, 2023	Public	View details	Change

Structures

Tracker | Fixed | East-West

Manufacturer	Model	Designed For	Type	Configuration	Max. modules/row	Max. rows/motor	Publication Date	Database	View details	Change
Generic (default)	Generic tracker	MONOFACIAL	Single-row	1V	60	1	May 12, 2023	Public	View details	Change

Project default equipment

Figure 5.3.2 The settings part of the equipment tab.

For more information on how to upload private equipment and to set up the default ones, check the following knowledge base articles:

- [How to upload your own equipment - Modules and Inverters](#)
- [How to upload your own equipment - Structures](#)
- [How to set up your own default equipment?](#)

5.3.1. PV Module

RatedPower has a database of PV modules that are widely used in utility-scale PV plants.

- Technology: Silicon Mono, Silicon poly, multi-crystalline, HIT and thin film. Bifacial modules are also permitted.
- PV cells: 60 and 72 cells.
- Voltage systems: 600V, 1000V, and 1500V.

Select a PV Module ✕

🔍 Search ⚙️ Filters

Company default

General	General610	1500	SI_MONO	Bifacial	Public	Show details
---------	------------	------	---------	----------	--------	------------------------------

Currently selected

Generic (default)	General610	610	1500	SI_MONO	Bifacial	Public	Show details
-------------------	------------	-----	------	---------	----------	--------	------------------------------

Manufacturer ↑	Model ↓	Power [W] ↓	Voltage [V] ↓	Technology ↓	type ↓	Database ↓	
AE SOLAR	AE SOLAR AE_165P6-36	165	1000	SI_POLY	Monofacial	Public	View details
AE SOLAR	AE SOLAR AE 165P6-36	165	1000	SI_POLY	Monofacial	Public	View details
AE SOLAR	AE SOLAR Thunder AE415BMC-60F	415	1000	SI_MONO	Monofacial	Public	View details
AE SOLAR	AE SOLAR Thunder AE410BMC-60F	410	1000	SI_MONO	Monofacial	Public	View details
AE SOLAR	AE SOLAR THUNDER AE405SMB-66F	405	1500	SI_MONO	Monofacial	Public	View details
AE SOLAR	AE SOLAR Thunder AE405BMC-60F	405	1000	SI_MONO	Monofacial	Public	View details
AE SOLAR	AE SOLAR THUNDER AE400SMB-66F	400	1500	SI_MONO	Monofacial	Public	View details
AE SOLAR	AE SOLAR THUNDER AE395SMB-66F	395	1500	SI_MONO	Monofacial	Public	View details

Figure 5.3.1.1. Modules public database.

5.3.2. Inverter

RatedPower has a database of central inverters and string inverters.

- Type: Central & string inverters.
- Voltage systems: up to 1500V.

Select a Inverter Select a Inverter ×

Central Inverter String Inverter Q Search ≡ Filters

Company default 🗖

Generic (default)	Generic 2310	2310	2310	1500	98.72	Public	Show details
-------------------	--------------	------	------	------	-------	--------	------------------------------

Currently selected

Generic (default)	Generic 2310	2310	2310	1500	98.72	Public	Show details
-------------------	--------------	------	------	------	-------	--------	------------------------------


Manufacturer ↑	Model ↓	Pmax [kVA] ↓	Phom [kVA] ↓	Max Voltage [V] ↓	Efficiency [%] ↓	Database ↓	
ABB	PVS980-58-4782kVA-K prelim rev. C	4782	4652	1500	98.33	Public	View details
ABB	ULTRA-1500.0-TL	1560	1560	1000	98.04	Public	View details
ABB	CORE-1000.0-TL	1100	1000	1000	97.69	Public	View details
ABB	PVS980-58-1818kVA-I	2000	1818	1500	98.11	Public	View details
ABB	PVS980-58-2000kVA-K	2200	2000	1500	98.22	Public	View details
ABB	PVS980-58-1909kVA-J	2100	1910	1500	98.16	Public	View details
ABB	PVS980-58-2091kVA-L	2300	2091	1500	98.33	Public	View details
ABB	ULTRA-700.0-TL	780	780	1000	97.82	Public	View details
ABB	ULTRA-1500.0-HD-TL-US	1560	1560	1000	98.04	Public	View details
Advanced Energy Inc.	Solaron 500/E	505	500	600	98.60	Public	View details

⏪ < 1 of 73 > ⏩

Cancel Set as default Select

Figure 5.3.2.1. Inverters public database.

To switch between central and string inverters, click on the respective type of inverter as shown in Figure 5.3.2.2.



The screenshot displays the 'Equipment' configuration page. At the top, there are buttons for 'Show details' and 'Change Module'. Below this is the 'Inverter' section, which includes a 'How to' link and two tabs: 'Central Inverter' (selected) and 'String Inverter'. Under the 'Central Inverter' tab, the 'Primary Inverter' configuration is shown. The 'Pmax [kVA]' field is highlighted with a red box and contains the value '2310'. Other fields include 'Manufacturer: Generic (default)', 'Model: Generic 2310', 'Pnom [kVA]: 2310', 'Max Voltage [V]: 1500', and 'Database: Public'. At the bottom of the primary inverter section are 'Show details' and 'Change Inverter' buttons. Below the primary inverter is the 'Secondary Inverter' section, which is currently active (indicated by a blue box around the toggle switch). It also shows 'Manufacturer: Generic (default)', 'Model: Generic 2310', and 'Pmax [kVA]: 2310'.

Figure 5.3.2.2. Changing the inverter's rated power.

As shown in Figure 5.3.2.2, inside the red box, **RatedPower** allows users to modify the inverter rated power. The rated power value at 30°C is the one shown by default.

A secondary inverter can be used as well by clicking on the blue box shown in Figure 5.3.2.2. This opens the list of central inverters for the user to choose from. This option could help optimize smaller plants (increase the filling) by choosing a smaller secondary inverter to make use of any spaces that were left empty.

In the case of East-West structures, the user can also define the Maximum Power Point Tracking (MPPT) configuration at the inverter. Available options are:

- Single MPPT inverter: Strings from east and west tables are connected to the same MPPT.
- Multiple MPPT inverter: Strings from east tables are connected to a different MPPT than strings from west tables.
- Separate inverters: Strings from east tables are connected to a different inverter than strings from west tables.




Figure 5.3.2.3. MPPT configuration at the inverter.

NOTE: Our inverters database is continuously updated with new commercial equipment. The client can also upload his own equipment to his private database using a .ond file of the inverter.

5.3.3. Structure

5.3.3.1. Type of Structure

RatedPower allows choosing between three different types of structure from our database:

- **Fixed structures:** Generic fixed structures of different configurations varying from 1V to 6V (portrait) and from 1H to 12H (landscape).
- **Single-axis trackers:** Monofacial and bifacial trackers from the main manufacturers and some generic ones as well. These come in different configuration options.
- **East-West structures:** Generic east-west structures of different configurations varying from 1V to 6V (portrait) and from 1H to 12H (landscape).

In the Design Process, to switch between fixed structures, single-axis trackers and East-West structures, click on the respective type of structure as shown in Figure 5.3.3.1.




Figure 5.3.3.1. Structure database in the software.

NOTE: The equipment database is continuously updated. Clients can also send us the datasheet of a tracker, or a fixed/E-W structure and we can add it to our database.

5.3.3.2. Create a new Structure

To create one and use it in RatedPower, the user will need to go to the equipment tab, select structures, and then click on the “Create new structure” button. After that he will be prompted to add some information regarding the structure, including the name, maximum number of modules, configuration, number of posts, etc. In this example, the images shown below are regarding a single axis tracker, but the procedure will be similar for fixed and E-W structures, but with less information added.







Figure 5.3.3.2. Creating a new structure.

5.3.3.3. Layout Configuration

The PV modules connected in series per string are calculated based on:

- The technical properties of the modules: voltage STC and voltage coefficient.
- The technical properties of the inverters: minimum MPPT voltage and maximum voltage.
- The minimum historic temperature of the site.
- The maximum historic temperature of the site.

RatedPower will recommend a range of modules per string by complying with the electrical characteristics and temperature values stated above. However, clients can select a number of modules per string outside of the recommended range.

In addition, the application takes into account that the modules per string that are chosen must comply with the structural limitation of modules per row. To understand this point, consider the following example.

Let's consider that a **1 V structure is limited to 60 modules per row** (just an assumption) and the range of modules per string is from 13 to 25.

- If the user chooses **18 modules**, and 3 Strings per structure the structure will be configured with $18 \times 3 = 54$ **modules per row** (maximum value of modules per row for this example). This results in a structure length of 62.3 meters approximately.




Figure 5.3.3.3.1. Layout configuration example. 18 modules per string.

- If the user chooses **21 modules**, the maximum value of strings per structure will be reduced to 2 instead of 3 because with 3 strings per structure we would exceed the upper limit: $21 \times 3 = 63$ modules per row $>$ 60 modules per row = Structure limit.




Figure 5.3.3.3.2. Layout configuration example. 21 modules per string.

- If the user chooses smaller string/structure values, the user will have shorter structures. Shorter structures designs could help to be adapted according to the land plot shape. Here we can see an example with **15 modules per string** and choosing for one case 4 strings per structure (maximum) and in the other 1 string per structure (minimum).





Figure 5.3.3.3.3. Layout configuration examples. 15 modules per string.

Users can choose the desired number of strings per structure. But RatedPower will always give a default recommended value. This recommended value will be the maximum one for trackers.

However, in the case of fixed structures, the recommended strings per structure will be the one that makes the structure length as close as possible to 25m and the maximum number of strings per fixed structure is the one that makes the structure length 80m.

For all kinds of structures, the minimum value will be 1 string per structure.


When choosing linked-row trackers, the user can also define the number of rows per linked-row. The minimum value is 2 and the maximum is the one given by the linked-row tracker manufacturer.



The screenshot shows a configuration panel with three rows. The first row is 'String per structure' with a value of 3 and a range of 'Min: 1 / Max: 3'. The second row, 'Structures per linked-row tracker', is highlighted with a red border and has a value of 2 with a range of 'Min: 2 / Max: 28'. The third row is 'Structure length' with a value of 78.78 m.

Figure 5.3.3.3.4. Number of structures per linked-row.

There's also a feature in RatedPower named partial structures, and it allows the user to have structures of different lengths (partial or broken structures). This will be available only if the general strings per structure is above 1. If the system only allows 1 string per structure, then partial structures will be disabled.



The screenshot shows two main sections. The top section has 'Strings per structure' set to 3 (range 'Min: 1 / Max: 3') and 'Structure length' set to 62.3 m. The bottom section, titled 'Partial structures', contains a dropdown menu for 'N° strings per structure' currently showing '2 (41.52 m), ...'. Below the dropdown are two options: '2 (41.52 m)' with a checked checkbox and '1 (20.75 m)' with an unchecked checkbox.

Figure 5.3.3.3.5. Partial structures.

It is important to understand this point in order to design the PV plant adequately. Additional information can be found in the [Electrical Methodology](#).

5.3.3.4. Mounting System

Users can modify the minimum ground clearance which is the minimum distance between the ground and the lower part of the structure. In the case of trackers, it is calculated at the maximum tracking angle of the chosen tracker. Apart from this parameter, the user can define the minimum pile length for all structures.

In the case of fixed structures or East-West structures, users can opt between a mono-pole or a bi-pole mounting system (and a tri-pole for East-West structures only). The tilt angle is another parameter exclusive to these structures. The software recommends a certain value based on the site latitude as follows:

We recommend these values for the tilt regarding the latitude:

Latitude	Recommended tilt
<5°	5°
5°-10°	latitude
10°-20°	latitude*0.9
>20°	latitude*0.85

In the case of East-West structures, the Ridge Distance can also be defined. This is the distance between the two opposite tables of the structure.

5.3.3.4.1. Trackers

Mounting System


Minimum Ground Clearance ⓘ m

Minimum pile length ⓘ m
Min: 1.57 m

[Schematic diagram](#)

Figure 5.3.3.4.1.1. Structure mounting system for trackers.

The pile length for trackers is calculated as shown in Figure 5.3.3.4.1.2.



$$\text{Pile Length} = \text{Post Depth} + \text{Minimum Ground Clearance} + (\text{Table width}/2) * \sin(\text{Tracker Limit})$$

Figure 5.3.3.4.1.2. Pile length for trackers.

5.3.3.4.2. Fixed structures

Mounting System

Mono-Pole

Bi-Pole

Tilt Angle 37 °


Minimum Ground Clearance 0.5 m

Minimum pile length 3.98 m
Min: 2.48 m

[Schematic diagram](#)


Figure 5.3.3.4.2.1. Structure mounting system for fixed structures.

The pile length for fixed structures is calculated as shown in Figure 5.3.3.4.2.(2 & 3).



$$\text{Pile Length} = \text{Post Depth} + \text{Minimum Ground Clearance} + (\text{Table width} \cdot 2/3) \cdot \sin(\text{Tilt angle})$$

Figure 5.3.3.4.2.2. Pile length for mono-pole fixed structures.



$$\text{Pile Length} = \text{Post Depth} + \text{Minimum Ground Clearance} + (\text{Table width} \cdot 3/4) \cdot \sin(\text{Tilt angle})$$

$$\text{Short pile length} = \text{Post Depth} + \text{Minimum Ground Clearance} + (\text{Table width} \cdot 1/4) \cdot \sin(\text{Tilt angle})$$

Figure 5.3.3.4.2.3. Pile length for bi-pole fixed structures.

5.3.3.4.3. E-W Structure

Mounting System

Mono-Pole

Bi-Pole

Tri-Pole

Tilt Angle 10 °

Ridge Distance 30 cm

Minimum Ground Clearance 0.5 m

Minimum pile length 2.07 m
Min: 1.07 m

[Schematic diagram](#)

Figure 5.3.3.4.3.1. Structure mounting system for fixed structures.




Figure 5.3.3.4.3.2. Pile length for East-West structures.

5.3.4. Power Station

Inverters can be placed either inside the power stations (PSs) or outside of them, in the PV field.

Depending on which type of inverter is used, different parameters can be modified.

In the case of central inverters, the user can choose how many inverters to have per Power Station, as shown in Figure 5.3.4.1.

The software starts placing the PSs with the selected number of inverters. If no more PSs can be placed, the software will try to place the next power station with one less inverter. This will continue until no more power stations can be installed.

RatedPower reduces the number of inverters per PS by one until the whole plant is filled with power stations. The user can choose the options he wants for the power stations by selecting the desired options.

Main Power Station

Number of Primary Inverters ⓘ

Secondary Power Stations

Select the types of PS to install in your plant.

- Select all
- PS 1: 4 primary inverters
- PS 2: 3 primary inverters
- PS 3: 2 primary inverters
- PS 4: 1 primary inverters

Figure 5.3.4.1. Central inverters per power station.

When the secondary inverter option is enabled, the user can also select the number of secondary central inverters per PS as shown in Figure 5.3.4.2. When this option is enabled, the default value for the number of secondary inverters per PS is zero. This means that the software will only place power stations equipped with primary inverters following the previous criterion. And when no more power stations of those can fit, it starts trying to place power stations with secondary inverters.

If, however, the number of secondary inverters per PS is modified to another value, the criterion that is followed is similar to the first one. For instance, let's consider that we want the PS to have 2 primary and 2 secondary central inverters. The software starts by placing power stations of this configuration. Once no more power stations can fit, it places PSs with 2 primary and 1 secondary inverter. After that it's 2 primary inverters only, then 1 by 1. And finally, the software checks whether it can fit a PS with 1 secondary inverter. As with the previous option, the user can select the different configurations of power stations that they want the software to use.

Main Power Station

Number of Primary Inverters ⓘ

Number of Secondary Inverters ⓘ

Secondary Power Stations

Select the types of PS to install in your plant.

- Select all
- PS 1: 4 prim. inverters/ 1 sec. inverters
- PS 2: 4 prim. inverters/ 0 sec. inverters
- PS 3: 3 prim. inverters/ 2 sec. inverters
- PS 4: 3 prim. inverters/ 1 sec. inverters
- PS 5: 2 prim. inverters/ 3 sec. inverters
- PS 6: 3 prim. inverters/ 0 sec. inverters
- PS 7: 2 prim. inverters/ 2 sec. inverters
- PS 8: 1 prim. inverters/ 4 sec. inverters

[Show all PS](#)

Figure 5.3.4.2. Central inverters per power station with secondary inverters enabled.

On the other hand, for string inverters, two parameters can be modified: the number of string inverters which the user wants to have per power station and the minimum allowable number. If no inverters can be placed based on the values selected, no more power stations will be placed.

Main Power StationN° of primary
inverters **Secondary Power Stations**Min. n° of inverters
per secondary PS

Select the types of PS to install in your plant.

- Select all
- PS 1: 5 primary inverters
- PS 2: 4 primary inverters
- PS 3: 3 primary inverters
- PS 4: 2 primary inverters
- PS 5: 1 primary inverters

Figure 5.3.4.2. String inverters per power station.

5.3.4.1. Transformer configuration

For every power station, the user can select the transformer configuration. By selecting the number of transformers inside the power stations, the type of each transformer (2-Winding or 3-Winding) and their capacity. These options are shown in figure 5.3.4.1.1.

Transformers

Select the power station to customize

Selected PS PS Main: 5 primary inverters

Number of transformers ⓘ ▾

Transformer n° 1

2-Winding



3-Winding



The selected transformer contains 5 primary inverters

Capacity MVA
Min: 11.55 / Max: 15.01

Short-circuit impedance of selected PS %
Min: 5.0% / Max: 12.5%

Figure 5.3.4.1.1. Transformers.

For the capacity, the software will give the user a range of values. The minimum is calculated by multiplying the number of inverters by the Pmax of one inverter. In the figure above, the selected inverters have a Pmax = 2310 kVa and the minimum capacity is equal to $5 * 2310 = 11\,550 \text{ kVa} = 11.55 \text{ MVA}$. The maximum value is equal to the minimum capacity plus 30%.

Users also have the possibility to set the short-circuit impedance of the power station.

5.3.4.2. Transformer losses

Users can also modify the power station transformer losses and define the iron and copper losses as shown in Figure 5.3.4.2.1.

Transformer Losses

Power Station

Iron loss	<input type="text" value="0.1"/>	%
Copper loss	<input type="text" value="1.0"/>	%

Figure 5.3.4.2.1. Power station transformer losses.

5.4. Layout Tab

In the case of having several available areas, **RatedPower** offers the possibility of applying a different configuration for each area or group of areas, using the switch shown in picture 5.4.1. A group of areas is created when the user uses the "Group areas in LV" option.




Figure 5.4.1. Multiple AA layout configuration options.

5.4.1. LV grouping

At the top left of the screen, the 'Group areas in LV' option is displayed.



Figure 5.4.1.1. Group area in LV (low voltage) option.

This feature allows low-voltage DC cables to be shared between areas in the case of a central inverter, and low-voltage AC cables to be shared between zones in the case of string inverters. In this way, a power station can be shared between several areas.

After clicking on the 'Group areas in LV' button, the user can select the areas to be grouped. He can also select the polygon in which the structures will be placed first by clicking on 'Priority AA' and placing the zone in question first.


For more information, read the following article: [How to interconnect your available areas in LV](#).

5.4.2. Power Requirements

RatedPower gives the possibility of choosing between installing the maximum capacity or a specific one.

In the case of maximum capacity, the software tries to optimize the site by installing the maximum “Rated Power” using the target DC/AC Ratio defined.

The user can also enable the “Install the maximum peak power” check box. By activating this option, all possible structures will be installed in the PV plant, reaching the maximum possible peak power by varying the DC/AC ratio inside the limits set below.



^ Power requirements	
Maximum Capacity	Specific Capacity
DC/AC ratio	2.1
<input checked="" type="checkbox"/> Install the maximum peak power ⓘ	
Lower limit	1.95
	Min: 1.8
Upper limit	2.25
	Max: 2.4

Figure 5.4.2.1. Power requirements for specific capacity.

In the case of specific capacity, however, the user can choose the number of inverters (for both the primary and the secondary inverter if any), as well as the DC/AC ratio. By modifying these parameters, the desired rated and peak powers can be achieved. An example of that with the secondary inverter present can be seen in Figure 5.4.2.2.

In the case of “Specific Power”, the layout will be developed near the MV Delivery Point / Substation to minimize cabling.

Maximum Capacity	Specific Capacity
Number of Primary Inverters	<input type="text" value="10"/>
Number of Secondary Inverters	<input type="text" value="0"/> inverters
Rated Power (approx.) ⓘ	<input type="text" value="3.3"/> MWac
DC/AC ratio	<input type="text" value="1.2"/>
Peak Power (approx.) ⓘ	<input type="text" value="3.96"/> MWdc

Figure 5.4.2.2. Power requirements for specific capacity.

The rated power is the installed AC capacity, and it depends on the chosen number of inverters and their technical properties. The peak power is the DC capacity, and it depends on the chosen DC/AC ratio.

In the case of selecting the “Specific Power” option, the structures will be spread over the various areas of the site based on three different criteria. The first criterion tries to occupy the least number of areas possible (one area only if possible). The second criterion tends towards selecting the closest areas over the far ones. And the third criterion intends to occupy the least percentage possible out of each area (partially occupy areas rather than completely occupy them). The software gives more priority to the first criterion, then the second one and finally the third one. It then rates different scenarios and selects the best option out of them.

The user can also define a power limitation at the delivery point as shown in Figure 5.4.2.3.

Energy Clipping

Power limitation at Delivery Point

Active Power limit ⓘ MW

If this value is zero, all energy production will be cut-off at the substation output.

Figure 5.4.2.3. Power limitation at delivery point.

Users also have the possibility to select the type of layout they want as shown in figure 5.4.2.4. If they choose the regular block design option, the same power station shape will be repeated in the layout, using a shape that is as square as possible. If they choose the adaptative design option, the available area of the site will be covered using blocks of structures. The size of the block depends on the chosen DC/AC ratio.




Figure 5.4.2.4. Type of Layout.

5.4.3. Distances

The user can define some distances for the layout configuration as shown in Figure 5.4.3.1.

Pitch distance	<input type="text" value="6.200"/>	m
		Min: 2.46m
Clearance distance	<input type="text" value="3.735"/>	m
GCR	<input type="text" value="40.0"/>	%
Distances between structures		
	<input type="text" value="0.500"/>	m
Min. distance from structures to fence		
	<input type="text" value="3"/>	m
Schematic diagram		

Figure 5.4.3.1. Layout configuration.

The pitch distance is defined in the application as the distance between the axis of two consecutive structures.

Users can choose the desired pitch distance between structures. **RatedPower**, however, always gives a default recommended value. This recommended value ensures 40% of Ground Coverage Ratio (GCR) in the case of trackers.

In the case of fixed structures, the recommended pitch distance makes sure that at least 4 hours of non-shaded production is achieved on the most unfavorable day of the year (the shortest day of the winter solstice).

For E-W structures, the pitch distance is calculated as follows:

- **RatedPower** calculates the minimum pitch distance: the one that makes the clearance distance 0.
- It then adds an industry standard clearance distance value:
 - For 1H or 1V: 0.3 m
 - For 2V or 2H: 1 m
 - For other configurations 2 m

Users can also modify the clearance distance between the structures and the GCR. The clearance distance is the free space between the structures. The pitch distance, clearance distance and GCR are dependent on each other, thus changing one value also modifies the others.

The user can also define the distance between structures as well as the distance between the structures and the perimeter.

Figures 5.4.3.2. and 5.4.3.3. show the difference between the pitch distance and the distance between structures for both fixed structures and trackers.




Figure 5.4.3.2. Pitch distance and distance between consecutive structures in fixed structures.




Figure 5.4.3.3. Pitch distance and distance between consecutive structures in trackers

5.4.4. Layout configuration

5.4.4.1. Roads Layout

This consists of defining the configuration of the internal roads of the PV plant:

- **Only horizontal roads:** The route of the roads will connect all the Power Stations following an East-West direction to the access points of the plots.
- **Horizontal and perimeter roads:** The route of the roads will connect all the Power Stations following an East-West direction and the perimeter roads with access points of the plots.
- **Only vertical roads:** The route of the roads will connect all the Power Stations following a North-South direction to the access points of the plots.
- **Vertical and perimeter roads:** The route of the roads will connect all the Power Stations following a North-South direction and the perimeter roads with access points of the plots.
- **Full perimeter roads:** This option surrounds all the structures of an area by a perimeter road where the power stations are placed. This configuration is only available for designs of no more than 5 power stations.
- **Minimal perimeter roads:** This option places all the power stations in the perimeter of the site and connects the power stations to the available area access point minimizing the road length. This configuration is only available for designs of no more than 5 power stations.

- **No roads:** This option places the power station close to the access point and no roads will be planned on site. This configuration is only available for designs with 1 power station or less than 5ha per available area (AA). User-defined "shortcuts" will not be considered for this option either.

Roads ⓘ

<p>Horizontal roads</p>	<p>Horizontal and Perimeter roads</p>
<p>Vertical roads</p>	<p>Vertical and Perimeter roads</p>
<p>Full perimeter roads</p>	<p>Min. perimeter roads</p>
<p>No roads</p>	

Width m

Figure 5.4.4.1. Example of the road configurations.

The width of the roads can also be modified in this section.

5.4.4.2. Structure alignment

In this section, the user can select the structure alignment with respect to the border of the parcel. There are two options: uniform arrangement and border adaptation.




Figure 5.4.4.2. Adaptation mode.

5.4.4.3. Rotation

RatedPower allows the user to choose the structure position that he desires between the four available options that are shown in Figure 5.4.4.3.




Figure 5.4.4.3. The four different structure positions.

The first two options, standard and rotated layout, are available for all types of trackers and fixed structures. Layout offset and layout turning angle axis, however, are only available for single-row trackers and fixed structures.

By default, single-axis trackers will be installed following the N-S direction, and fixed structures following the E-W direction.

The rotated layout, layout offset, and layout turning angle axis options allow modifying the turning angle shown inside the red box in Figure 5.4.4.3.



The UTM convergence correction can be enabled or disabled. This option will apply a rotation in the structures to counteract the UTM convergence effect.

If the UTM convergence correction is enabled, the structures will be aligned with the real North-South axis (or East-West for fixed structures) in the WGS 84 geographical coordinate system. A rotation may then appear in the Layout DXF coordinates, in the UTM coordinate system.

5.4.5. Power station location

RatedPower gives the user the choice to select between placing the power station inside or outside the DC field. If the “Inside the DC field” option is chosen, structures are removed from the field to put the PSs in their place, thus reducing the margins left for the internal roads. This helps to increase the filling of the PV plant. The user can also modify the dimensions of these power stations as shown in Figure 5.4.5.

Location

Outside DC field	Inside DC field
	

Dimensions ⓘ

Length	<input type="text" value="12.192"/>	m
Width	<input type="text" value="2.438"/>	m
Height	<input type="text" value="2.438"/>	m

Figure 5.4.5. Power station options.

5.4.6. Setbacks


It is possible to customize the distance between certain elements of the PV plant, and those can be divided into two sections: AA setbacks, and RA setbacks.

In the **AA setbacks**, prior to start defining the distances, the users have the option to choose the fence strategy they would like to use. It can either follow the AA perimeter, or to minimize the fence as much as possible close to the structures. It also includes distances such as from the area’s perimeter to the fence, or from the power stations to the structures as shown in Figure 5.4.6.1. The minimum value for the Fence to structure is 2 m. For the Power Station (PS) to road setback and the structures to road setback, the minimum value is 1.5 m.


^ **AA Setbacks**

Fence structure

Follow the AA perimeter (i)



Minimize fence length (i)



Setbacks

Available Area (AA) to fence	0.0	m
Fence to structure	3.0	m
Power Station (PS) to structure	2.0	m
Power Station (PS) to road	1.5	m
Structure to road	1.5	m

Figure 5.4.6.1. AA Setbacks.

Figure 5.4.6.2 allows the user to visualize what each setback refers to.




Figure 5.4.6.2. Schematic diagram for AA setbacks.

The **RA setbacks** allow us to do a variety of configurations, especially when we are using different types of RAs, as shown in Figure 5.4.6.3. Those can be described as:

- **RA Name**- Can choose a name that will be shown in the layout and documentation.
- **RA Color**- Can either select a color or type in the color code.
- **Fence strategy**- Choose from the 3 options the most suitable fence strategy for the layout. Not available for substation (ST) and SBS (Switching & Breaking Station).
- **Setbacks**- Define the distances from the RA to structure, and from RA to fence.
- **Road strategy**- Choose from the 2 options the most suitable road strategy for the layout. Not available for substation (ST) and SBS (Switching & Breaking Station).

^ RA Setbacks

RA-1

RA-2

RA-3


ST

RA Name


RA Colour

Fence strategy


Prevent the fence from crossing RA ⓘ



Keep RA inside the PV plant ⓘ



Let the fence cross RA ⓘ



Setbacks


Restricted Area (RA) to structure m

Restricted Area (RA) to fence m

[Schematic diagram](#)

Road strategy

Minimise crossing the RA (shortcuts) ⓘ



Cross directly the RA ⓘ




Figure 5.4.6.3. RA Setbacks.

There are 3 strategies for the fences around the restricted areas, which can be described below:

- 1. Prevent the fence from crossing the RA



Figure 5.4.6.4. Schematic diagram for RA setbacks.

- 2. Keep RA inside the PV plant



Figure 5.4.6.5. Schematic diagram for RA setbacks.

3. Let the fence cross RA




Figure 5.4.6.6. Schematic diagram for RA setbacks.

5.5. Topography

5.5.1. Topography limitation tool

RatedPower offers a topography limitation and earthworks tool. It allows users to set different criteria. These criteria are:

- The maximum North-South slope limit (structure installation limit), with the possibility of setting a common limit for both slopes or to differentiate between each orientation.
- North-South Earthworks between the structure installation limit and a maximum value (apply earthworks up to).
- The maximum East-West slope limit (structure installation limit).
- East-West Earthworks between the structure installation limit and a maximum value (apply earthworks up to).
- The maximum post length limit (Undulation tolerance).
- Terrain undulation Earthworks between the structure installation limit and a maximum value (apply earthworks up to).
- The linked-row installation limit.




Figure 5.5.1.1. RatedPower's topography analysis tool.

To apply the limitations defined with the tool, the option to remove the structures that exceed the limits needs to be enabled.




Figure 5.5.1.2. Apply topography limitations.

All criteria (except for the linked-row criterion) have two options, an installation or tolerance limit, and an earthworks mode.

The linked-row structure limit option is only available when a linked-row tracker is selected.




Figure 5.5.1.3. RatedPower’s topography analysis tool for linked-row.

This option allows the user to set a slope limit. For example, with slope limit at 5% as shown in the image above, **RatedPower** will remove any linked-row tracker which has a slope of 5% or above between its rows (not underneath them). Even if a linked-row tracker consists of 12 rows and the slope between only 2 of these rows is above the set limit, the whole linked-row tracker will be eliminated from the final design.

To apply the North-South criterion, the first step is to activate the "Apply limits and earthworks" button.

After that, two options will be available for the user to choose from:

- Apply the same value for both slopes.
- Differentiate between north and south slopes.




Figure 5.5.1.4. RatedPower's topography analysis tool.

Option 1: Same values for both slopes

If the user chooses this option, the software will check the slope value below the structure (whether it's a tracker or a fixed structure) in the north-south direction. For example, using the example shown in the image below, any structure installed above a north-south slope of 7 % or more will be removed from the final design.




Figure 5.5.1.5. RatedPower's topography analysis tool for North-South criteria

Option 2: Differentiate between north and south slopes

This option allows the user to set an installation limit and choose whether or not to apply earthworks for North Slopes and South slopes. He can either choose to set limits for both slopes or only one by clicking on the checkboxes. The logic used by the software for the removal of structures and the application of earthworks is the same as in the case of option 1.




Figure 5.5.1.6. Topography analysis tool with North-South differentiation.

To apply the East-West criterion, the first step is to click on the "Apply Limits and Earthworks" button. For this criterion, the user can only apply the same limit for both East and West-facing slopes (similar to option 1 for North-South slopes).




Figure 5.5.1.7. RatedPower's topography analysis tool for East-West criteria.

The final criterion is the terrain undulation criterion. This parameter allows the user to set a maximum limit on the difference in pile length between the shortest and longest pile of the same structure.




Figure 5.5.1.8. RatedPower's analysis tool for undulation tolerance criterion.

The figure below provides a visual representation of what this refers to.




Figure 5.5.1.9. Visual representation of how the undulation tolerance limit works.

5.5.2. Earthworks

RatedPower also allows to apply earthworks to the terrain underneath a structure that exceeds the slope limits. The user will need to define a range of slope percentages. For the structure within this range, all the necessary cuts and fills to reduce the slope will be applied. However, if the slope is initially above the range, the structure will be removed from the final design. The slope limitation can be defined in the North-South direction or the East-West direction.

North-South ⓘ

Apply limits and earthworks
 Same values for both slopes
 Differentiate north and south-facing slopes

Structure installation limit %

Earthworks up to %

10.00% 25.00%

Installed w/o earthworks
 Installed with earthworks
 Exceeding the installation limit

Figure 5.5.2. RatedPower's earthwork tool example.

In this example, the structures will be distinguished according to the slope underneath in the North-South direction:

- <10%: the structure will be installed without earthworks.
- between 10% and 25%: the structure will be installed but cut and fill will be applied to decrease the slope to 15%.
- >25%: the structure will not be installed.

Based on these results, **RatedPower** will calculate the total necessary cut and fill volume and include these values in the Design Report and the BOQ. It will also generate a Listing of Posts spreadsheet, a Topography Analysis DXF, and a Structure Profiles zip file that includes various CAD files.

5.5.3. Preview

The status of the different structures can be seen in the map following the colors shown in the tools:

- **light blue** : these structures will be installed.
- **dark blue**: these structures will be installed but are outside certain limits. This will be the case if the slope limit is selected but the option to remove structures that exceed the limits is not enabled.
- **orange**: these structures will be installed but will require earthworks.
- **light brown**: these are earthworks platforms or boundaries, which include the different groups of structures where earthworks will be applied simultaneously.
- **green**: these structures will not be installed because they exceed the slope limit and the option to remove structures that exceed the limits is enabled.
- **purple**: these structures will not be installed because they exceed the undulation tolerance limit and the option to remove structures that exceed the limits is enabled.




Figure 5.5.3. preview of the structures with topography limitations.

5.6. Grid Point

5.6.1. Electrical standards

RatedPower allows users to size their interconnection facility based on two electrical standards such as IEC or IEEE, as well as select the maximum current for the MV lines and the voltage level of the medium voltage system. The range of the MV system is between 5 and 45 kV, and it is connected in branches (lines), not in a ring connection.

Electrical Standard ⓘ

IEC	IEEE SA
	
MV lines maximum current ⓘ	500 A
MV level	34.5 kV

Figure 5.6.1. Electrical standards for sizing the interconnection facility.

5.6.2. Connection Type

RatedPower offers the basic engineering of a substation. Users can opt for a switching and breaking station or a generic substation.

The switching and breaking station is only enabled for PV plants of up to 100 MVA and a total current of no more than 2100 A. Its objective is to connect various medium voltage cables together and then to transmit them to the point of distribution or consumption. The step-up substation, on the other hand, elevates the voltage level from medium to high voltage.

If the user selects the step-up substation, they can choose to get an automatic result based on the size of your PV plant which could be a line to transformer, a single busbar or a double busbar substation. However, they can also opt to manually choose any of the three options. If the substation option is selected, the user can also define the high voltage level from 46kV to 400kV, as shown in Figure 5.6.2.1.

Interconnection facility

Switching and breaking station ⓘ

Substation ⓘ

Manually choose a type of arrangement for the substation

Single busbar arrangement ^

Double busbar arrangement

Line to transformer arrangement

HV level ⓘ kV
Min: 46 kV / Max: 400 kV

Figure 5.6.2.1. Connection type options.

In both cases, the user can also choose to set an overhead line voltage drop.

RatedPower also allows the users to configure the power transformers. They can select two or three winding transformers, or size the transformer based on the capacity or the number of bays. There's also the option to specify the output number of bays.

Select the power transformer type ⓘ

2-Winding 	3-Winding
---------------	---------------

Size power transformer manually ⓘ

Transformer capacity	Transformer bay No.
Power transformer capacity	70 MVA ▼
Short circuit impedance	8.00 % min: 3.57%

Set output bay manually ⓘ

Output bay number

rec: 1
min: 1
max: 8

Figure 5.6.2.2. The substation's transformer configuration.

5.6.3. Overhead Line

Users can also provide inputs for the overhead line or gen-tie. In the first part, there's the capacity over estimation, number of circuits and number of conductors per phase.

^ Overhead line

Capacity over estimation ⓘ MVA

Number of circuits ▼

Number of conductors per phase ▼

Figure 5.6.3.1. Overhead line configuration.

Following that, the user can pick the phase conductor type. There are two options here, one is AAAC (All aluminum alloy conductor), and ACSR (Aluminum conductor steel reinforced).

Phase Conductor ✕

AAAC ACSR 🔍 Search...

Currently selected

160-A2	19	3.51 mm	17.6 mm	506.1	54.32	183
Name ↓	Aluminum stranding ↓	Aluminum diameter ↓	Total diameter ↓	Unitary Mass ↓	Rated Strength ↓	Cross section ↑
16-A2	7	1.83 mm	5.49 mm	50.4	5.43	18
16-A3	7	1.84 mm	5.52 mm	50.8	6.04	18
25-A2	7	2.29 mm	6.86 mm	78.7	8.49	28
25-A3	7	2.3 mm	6.9 mm	79.5	9.44	29
40-A2	7	2.89 mm	8.68 mm	125.9	13.58	45
40-A3	7	2.91 mm	8.72 mm	127.1	15.1	46
63-A2	7	3.63 mm	10.9 mm	198.3	21.39	72
63-A3	7	3.65 mm	10.9 mm	200.2	23.06	73
100-A2	19	2.78 mm	13.9 mm	316.3	33.95	115
100-A3	19	2.79 mm	14 mm	319.29	37.76	116

⏪ < of 4 > ⏩

Cancel

Figure 5.6.3.2. Phase conductor configuration.

The two following tabs will let the user choose the earth wire and tower shape. RatedPower has 6 tower shapes available (3 per each number of circuits option).

Earth wire

Name: OPGW-2S 1/48B1 (0/165-213.7)

Total diameter: 17.2 mm

Unitary Mass: 48000 kg/m

Rated Strength: 106.3 kN

Elasticity: 109 GPa

Section: 16.5 mm²

Short circuit capacity: 213.7 kA² · s

Thermal expansion: 0.0000155

Unitary resistance: 0.27 Ω/km

[Change earth wire](#)

Figure 5.6.3.3. Earth wire configuration.

Tower shape

Single Fork

S Tower

Pi Tower

Tower shape




Figure 5.6.3.4. Tower shape configuration.


At the end of the overhead line section, the user can set a maximum voltage drop. **RatedPower** then dimensions the OHL to respect this limit. The actual calculated voltage drop is displayed directly below.

Maximum overhead line voltage drop	<input type="text" value="5.00"/> %
Voltage drop	0.0450 %

Figure 5.6.3.5. Overhead line voltage drop.

5.6.4. Losses

In this tab, the users can choose the losses for the transformer, and the overhead line voltage drop. It can be disabled as well.



<input checked="" type="checkbox"/> Substation Transformer losses	
Iron loss	<input type="text" value="0.1"/> %
Copper loss	<input type="text" value="1.0"/> %

Figure 5.6.4. The substation's transformer losses and overhead line voltage drop.

5.6.5. Grid requirements

In **RatedPower**, users can select whether they want to enable sizing using the power factor requirements (cosine of phi) or not. If this option is not selected, the reactive power will not be considered during the calculation process. If, however, this option is selected, the AC capacity will be calculated accounting for reactive power. There are 2 available strategies for power factor sizing and thus reactive power compensation:

- Installing additional inverters in the field to compensate reactive power.
- Adding both inverters in the field and capacitor banks in the substation.

^ Grid requirements How to [↗](#)

Sizing using power factor requirements (cosine of phi)

Reactive power compensation strategy and measurement point ⓘ

Use inverters only ⓘ
 Use inverters + capacitor banks ⓘ

Required power factor ⓘ
Min: 0.5 / Max: 1

Resulting power factor at the inverter's output ⓘ 0.9844

Inverter ST Output

Inverters POI

[Define strategy settings](#)


Figure 5.6.5.1. Power factor requirements.

Depending on the selected strategy, the user can also define where to measure the power factor and what value to measure there ('required power factor') by clicking on 'Define strategy settings'. As shown in Figure 5.6.5.2, for the inverter-only strategy, he can define this point either at the input or at the output of the substation.

Reactive power compensation strategy settings ✕

Choose the point of interconnection (POI) where the required power factor will be measured.

Required power factor ⓘ
Min: 0.5 / Max: 1



● INVERTERS

Resulting power factor at the inverter's output **0.9849**

Done

Figure 5.6.5.2. Reactive power compensation settings for the inverters-only strategy.

For the inverter and capacitor bank strategy, the user can define the power factor compensation point at the input of the substation, at the output of the substation or at the end of the overhead line (OHL) as shown in Figure 5.6.5.3.

Reactive power compensation strategy settings ✕

Choose:

- The point of interconnection (POI) where the required power factor will be measured.
- The point from where to start compensating with capacitor banks (capacitor banks are installed in the substation).

Required power factor ⓘ
Min: 0.5 / Max: 1

■ INVERTERS ■ CAPACITOR BANKS

Resulting power factor at the inverter's output **0.9974**

Done

Figure 5.6.5.3. Reactive power compensation settings for the inverter and capacitor bank strategy.

When sizing while the power factor option is enabled, the DC field is clearly affected. No matter what power factor is selected, the power factor at the inverter output (estimated cosine of phi) will be lower than 1 (due to various reasons like cable losses, transformer losses, substation losses, etc...). The plant will inject less overall active power and will generate/consume reactive power. This information can be checked in the Energy Yield Report in the "Yields and losses for the first year" table.

Applying a power factor has various effects on the electrical configuration and performance of the PV system. Assuming that no changes have been made to the PV module, the lower the power factor applied, the higher the DC/AC ratio will be (as the total active AC power decreases). However, to compensate for this effect, more capacitor banks and/or inverters are installed to achieve the same installed capacity.

For example, if the inverter only strategy and power factor is enabled in RatedPower, more inverters will be installed to compensate for the reactive power. This is better illustrated by the example in Figure 5, where more inverters need to be installed to maintain the same total PV plant capacity at a lower power factor.

Required power factor ⓘ 1	Resulting power factor at the inverter's output ⓘ 0.9972	Required power factor ⓘ 0.9	Resulting power factor at the inverter's output ⓘ 0.8717
Number of Primary Inverters 50 <small>inverters</small>	Rated Power (approx.) ⓘ 54.85 MWac	Number of Primary Inverters 57 <small>inverters</small>	Rated Power (approx.) ⓘ 54.66 MWac
DC/AC ratio ⓘ 1,2	Peak Power (approx.) ⓘ 65.82 MWdc	DC/AC ratio ⓘ 1,2	Peak Power (approx.) ⓘ 65.59 MWdc

Figure 5.6.5.4. PV plant with two different Power Factors
(a. Only inverters strategy).

This can be understood better by observing Equation 1.

Equation 1:

$$DC/AC \text{ ratio} = \frac{P_{DC}}{P_{AC}}$$

Where:

- P_{DC} is the peak DC power output of the PV plant.
- P_{AC} is the maximum AC power output of the PV plant. $P_{AC} = S_{AC} * \text{Power factor}$ (where S_{AC} is the total apparent AC power output of the plant). Thus, when the power factor is less than 1, P_{AC} becomes smaller thus increasing the DC/AC ratio.

5.7. Electrical

5.7.1. Solar field

5.7.1.1. String positioning within a structure

The string positioning within a structure could be chosen between:

- **Pitch grouping:** Strings will be formed favoring the connection of the modules in the pitch direction.
- **Axial grouping:** Strings will be formed favoring the connection of the modules in the axial direction.




Figure 5.7.1.1. String grouping.

This configuration will affect the length of string cables and the shading mismatch loss in energy production.

5.7.1.2. Configuration Type

There are two types of configurations in the case of central inverters and two in the case of string inverters. In the case of central inverters:

- **String Box:** The strings of modules are connected to a string box. And groups of string boxes are connected to central inverters.
- **DC Bus System:** The strings are connected to a DC Bus collector connected to a string box. The connections then reach the inverters.




Figure 5.7.1.2.1. Configuration available for central inverter

In the case of string inverters:

- **String Inverter (Field):** The strings are connected directly to the string inverters. The string inverters are located in the field (outside the power stations).
- **String Inverter (Station):** The string inverters, in this case, are located in the power stations.




Figure 5.7.1.2.2. Configuration available for string inverter

The user can choose the number of strings connected. This section will not appear for string inverters. If the user had chosen central inverters in the Equipment tab the next options would be available in this section:

- If the user chooses a **String Box** for the Low Voltage Electrical Configuration, the user will also be able to choose the maximum number of strings per box. To achieve an exact DC/AC ratio, other values of strings per box may also be used.

Maximum strings per box ⓘ 16 (244kW) ▾

Figure 5.7.1.2.3. Maximum strings per box for String Box Low Voltage Configuration.

- If the user chooses a **DC bus** type for the Low Voltage Electrical Configuration, the user will also be able to choose the maximum number of strings per DC bus. To achieve an exact DC/AC ratio, other values of strings per DC bus may also be used.

Maximum strings per DC bus ⓘ 16 (244kW) ▾

Figure 5.7.1.2.4. Strings per DC Bus for DC Bus System Low Voltage Configuration.

The strings per box and strings per DC Bus must be multiples of the number of strings per structure, defined in the Equipment tab.

RatedPower always gives 12 (or the closest possible number to 12) as a default recommended value.

The minimum value will be the number of strings per structure and the maximum value will be 32 (or the closest value less than 32).

The chosen value by the user will be used as much as possible but other numbers of strings per box or strings per DC Bus can be used by **RatedPower** to achieve the global DC/AC ratio desired by the user. To do so, **RatedPower** will try with configurations between half of the selected value and the maximum value.

To understand this better we can see the example:




Figure 5.7.1.2.5. Strings per box configuration example.


Here, the default value will be 16 and will be used as much as possible. However, in order to achieve the target DC/AC ratio, boxes of 14, 12, 10 and 8 can also be used.

There is no lower limit to the number of strings per box for designs that include partial structures, as it is possible to have structures that are smaller than the minimum size of a box.

5.7.1.3. Harness

It's possible to add DC harness cables to collect a certain number of strings into one before reaching the LV collector. The strings connected together need to be from the same structure. Thus, if the number of strings per structure is just 1, this option will not be available.

If this option is enabled, the number of strings per harness and the number of harnesses per collector can be defined.



Harness ⓘ
 Strings per harness ⓘ ▾
 Maximum harnesses per box ⓘ ▾

Figure 5.7.1.3. Harness configuration.

5.7.2. Cable Sizing

5.7.2.1. Electrical Standard

RatedPower gives users the option of choosing between four different electrical standards for sizing the cables. These different options are the IEC standard (International Electrotechnical Commission), the NEC (National Electrical Code), AUS (Australian standard) and CN (Chinese Standard).

Electrical Standard




Figure 5.7.2.1. Electrical standards for cable sizing.

Each standard calculates the cable and fuse sizes differently. The IEC, AUS and CN standards provide cable sections in mm^2 , while the NEC provides them in AWG (American Wire Gauge) and kcmil.

Additional information regarding the different criteria behind these two electrical standards can be found in our [Electrical Methodology](#).

5.7.2.2. Maximum voltage drops

Users can also choose the maximum allowed voltage drop percentage for both the DC side as well as the medium voltage side. The smaller these values are, the bigger cable dimensions are.

In the case of string inverters, users can also modify the AC side voltage drop limit.

Maximum Voltage Drop ⓘ

DC side	<input type="text" value="1.5"/>	%
AC side ⓘ	<input type="text" value="4.5"/>	%
MV system	<input type="text" value="0.5"/>	%

Figure 5.7.2.2. Maximum allowed voltage drops per subsystem.

5.7.2.3. Cables

The user can also choose the cross-sections they want to allow the software to take into account for the string cables, the AC cables and the MV cable. The software will then automatically choose the best section for each cable among those available. The software will reduce the number of different cables by choosing only one or two different cross-sections for each type of cable.

String cables

Sections ⓘ 4 mm2, 6 mm2... ^

- 4 mm2
- 6 mm2
- 10 mm2
- 16 mm2

AC cables

Sections ⓘ 25 mm2, 35 mm2... ^

- 25 mm2
- 35 mm2
- 50 mm2
- 70 mm2
- 95 mm2
- 120 mm2
- 150 mm2
- 185 mm2
- 240 mm2
- 300 mm2
- 400 mm2

MV cables

Sections ⓘ 95 mm2, 120 mm2... ^

- 95 mm2
- 120 mm2
- 150 mm2
- 185 mm2
- 240 mm2
- 300 mm2
- 400 mm2
- 500 mm2
- 630 mm2

Figure 5.7.2.3.1. Available sections for cable sizing.

The user can also define:

- **The maximum number of unified sections:** 1-3
- **The maximum number of circuits per polarity:** 1 or 2
- **The material:** Aluminum or Copper
- **The insulator type:** XLPE, EPR or PVC
- **The core:** single DC or Multiple DC
- If the cables are under **direct sunlight** (only available for string cables)

Cross-sections	<input type="text" value="4 mm2, 6 mm2..."/>
Max. number of cross-sections to use	<input type="text" value="2"/> Min: 1 / Max: 3
Maximum circuits per polarity	<input type="text" value="1"/> Min: 1 / Max: 2
Material	<input type="text" value="Cu"/>
Insulators	<input type="text" value="XLPE"/>
Cores	<input type="text" value="Single DC"/>
Direct sunlight	<input type="text" value="No"/>

Figure 5.7.2.3.2. Available options for cable.

5.7.2.4. Cable sizing parameter

The user can also set the ground temperature and the soil thermal resistivity. These parameters will impact the cable sizing.

5.8. BESS

In **RatedPower**, the user can design an AC-coupled battery energy storage system (BESS) or a DC-coupled BESS. DC-coupled BESS requires the use of a central inverter, while AC-coupled BESS requires the definition of an area for the BESS during site creation.




Figure 5.8. BESS type options.

5.8.1. AC coupled BESS

5.8.1.1. Power Conversion System

In this section within the BESS tab, the inverter type and the number of inverters per PCS are selected, thus establishing the power of the PCS or minimum unit of the system.

^ Power Conversion System

Storage inverter

Manufacturer: TMEIC

Model: Solar Ware 3360 - PVH-L3360GR(PRERELEASE)

Pmax [kVA]:

Pnom [kVA]: 3360

Max Voltage [V]: 1500

Database:

[Show details](#) Change Inverter

Inverters per PCS

Power per PCS 10080 kW

Figure 5.8.1.1. AC-BESS Power Conversion System.

5.8.1.2 Battery container

In **RatedPower**, we assume that the storage solution is modular. The user can set the capacity of a battery container. Alternatively, he can set the capacity of a single battery rack and the number of racks to include per container. And **RatedPower** will install the necessary number of containers according to the system requirements.

The screenshot shows two configuration panels for 'Battery container'. The top panel has 'Container' selected, with 'Energy installed per battery container' set to 3000 kWh. The bottom panel has 'Racks' selected, with 'Energy installed per rack' set to 250 kWh, 'Number of racks per container' set to 12, and 'Energy installed per battery container' set to 3000 kWh.

^ Battery container	
Container	Racks
Energy installed per battery container	3000 kWh

^ Battery container	
Container	Racks
Energy installed per rack	250 kWh
Number of racks per container	12
Energy installed per battery container	3000 kWh

Figure 5.8.1.2. Battery container.

5.8.1.3. BESS requirements

This section establishes both the power requirements and the supply hours of the BESS.

For the power requirements, maximum capacity or specific capacity can be chosen.

- **Maximum capacity:** with this option, the maximum possible power will be installed in the area defined for the BESS.

- **Specific capacity:** In this section, a specific size for the battery system can be configured by defining the number of PCS to install. The system power will be the multiple of the PCS power.

^ BESS requirements

Maximum capacity Specific capacity

Number of PCS 1

BESS Rated Power 1760 kW

Figure 5.8.1.3.1. AC-BESS requirements.

Then, the supply cycle duration is calculated as capacity (MWh) divided by rated power (MW).

Supply cycle duration ⓘ

Hours ⓘ 1.14 ^

^ BESS layout

PCS dimensions

Length

1.14
2.27
3.41
4.55
5.68
6.82

Figure 5.8.1.3.2. AC-BESS Supply Cycle Duration.

5.8.1.4. BESS layout

In the BESS layout section, the dimensions of both PCS and containers can be defined.

^ BESS layout

PCS dimensions

Length	<input type="text" value="6.1"/>	m
Width	<input type="text" value="2.438"/>	m
Height	<input type="text" value="2.59"/>	m

Battery container dimensions

Length	<input type="text" value="12.192"/>	m
Width	<input type="text" value="2.438"/>	m
Height	<input type="text" value="2.591"/>	m

Figure 5.8.1.4.1. AC-BESS Layout.

In addition, both the distance between adjacent blocks and the distance between opposing blocks can be defined. According to the NFPA 855 standard, the minimum safety distances between containers or between containers and PCS are 0.9144 m (3 ft) and 1.524 m (5 ft) respectively.

Distances

Distance between consecutive blocks ⓘ	<input type="text" value="4"/>	m
Distance between opposite blocks ⓘ	<input type="text" value="3"/>	m

[Schematic diagram](#)




Figure 5.8.1.4.2. AC-BESS Distances.

5.8.2. DC coupled BESS

In the case of the DC-coupled BESS, the BESS containers are placed next to the main power station inside the DC field as shown in Figure 5.8.2.




Figure 5.8.2. DC-BESS containers in the layout.

5.8.2.1. Power Conversion System

In this section, for DC-BESS, the user can set the parameters of the DC/DC converters (buck/boost converter). The first parameter to define is the DC/DC converter power. Once the maximum continuous power of each DC/DC converter has been set, the user can define the number of converters connected to one central inverter (this must be an integer number).

^ Power Conversion System

DC/DC converter

Pmax [kW]		1732.5	kW
Converters per inverter	ⓘ	2	
Power per inverter		3465 kw	
BESS/AC ratio	ⓘ	1.5	

Figure 5.8.2.1. DC-BESS Power Conversion System.

5.8.2.2 Battery container

For the battery container part, the options are the same for both AC coupled BESS and DC coupled BESS.

5.8.2.3. BESS requirements

This section establishes both the power requirements and the supply hours of the BESS.

The power requirements can be selected as maximum power or specific power. It works in the same way for AC and DC coupled BESS.

For the BESS supply duration, the final objective is to determine the number of battery containers required for each power station (PS). The user has the flexibility to select up to a maximum of 6 containers per PS. By default, the software pre-selects 1 container per PS. This is set by selecting the 'Minimum supply cycle duration' in hours from the drop-down menu. As a result, the interface displays the total number of battery packs per PS with storage and the maximum C-rate in [1/hour].

Supply cycle duration ⓘ

Hours ⓘ	0.43	^
Num of containers per PS	0.43	
	0.87	
C-rate	1.30	
	1.73	
▼ BESS layout	2.16	
	2.60	

Figure 5.8.2.3. DC-BESS Supply Cycle Duration.

5.8.2.4. BESS layout

In the DC-BESS layout section, the dimensions of the battery containers can be defined.

^ BESS layout

Battery container dimensions

Length	12.192	m
Width	2.438	m
Height	2.591	m

Figure 5.8.2.4.1. DC-BESS Layout.

In the same section, different setbacks can be also set:

- Power Station (PS) to Battery Container: This distance must be greater than 5 feet (1.524 m) according to the NFPA 855 standard.
- Distance between battery Containers (only if more than 2 Battery Containers per PS): The distance between battery containers must be greater than 3 ft (0.9144 m) in accordance with NFPA 855.
- Battery container to structure: This distance shall be greater than 5 feet (1.524 m) in accordance with NFPA 855.
- Battery container to road: It is possible to manually define the distance from the battery container to the road. The minimum value is 1.5m.

Distances

Container to PS	1.524	m
Container to structure	1.524	m
Between containers	0.914	m
Container to road	1.5	m

[Schematic diagram](#)





Figure 5.8.2.4.2. DC-BESS Distances.

5.9. Energy

5.9.1. Simulation

In this section, the user can choose the number of years of the simulation. This only affects how much data will be generated in the documentation.

The interannual variability (standard deviation) can also be defined. This value will be used to calculate the energy produced in P50, P75, P90, P95 and P99 scenarios. These values are available in the Energy Yield Report and the Energy Yield Results (first tab of the excel sheet).



The screenshot shows a 'Simulation' section with two input fields. The first field is 'Years of Simulation' with a value of 25. The second field is 'Interannual variability (standard deviation)' with a value of 3.00%. Below the second field, there are labels for 'Min.: 0.01 %' and 'Max.: 100 %'.

^ Simulation	
Years of Simulation	25
Interannual variability (standard deviation) ⓘ	3.00 %
	Min.: 0.01 %
	Max.: 100 %

Figure 5.9.1. Energy simulation parameters

5.9.2. Horizon

The solar irradiance reaching the photovoltaic modules will change if there are hills or mountains on the horizon. These physical obstructions will block the beam component of the irradiance during some periods of the day and will have an impact on the diffuse component as well. Therefore, the horizon profile directly impacts the energy yield of the photovoltaic plant.

RatedPower gets the horizon data from PVGIS 5. Unlike the meteorological data, the PVGIS 5 horizon database is available worldwide.

A flat horizon option (a horizon without any obstacles) is also available.

5.9.3. Surface Albedo

Surface albedo is the value that reflects the ratio of reflected light to that of the total incident sunlight at a certain site. It depends hugely on the type of surface (terrain) and its reflective characteristics.

RatedPower gives users the possibility to choose between various surface albedo options or choosing the MODIS sensor.

The MODIS (Moderate Resolution Imaging Spectroradiometer) albedo data source is a key instrument aboard the NASA Terra and Aqua satellites.

The data has a monthly temporal resolution and is derived from long term measurements taken from 2000 to 2017. The albedo value for each month is the average of all the available data values for that month. The spatial resolution is 0.1° in latitude and 0.1° in longitude, which is equivalent to a grid of 11x11km at the equator. At locations further from the equator, the resolution in kilometers increases.

[NASA Power albedo](#) can also be used in this section. It is available in all temporal levels from 1984 (2001 hourly) to within months of near real time (NRT). It uses both GEWEX SRB 4-IP and CERES SYNDEg Ed. 4.1. Its calculation is based on the ratio of the sunlight reflected by the surface of the earth to the total solar energy incident on the surface. The horizontal resolution of the primary solar data source is a global 1° in latitude and 1° in longitude grid, while the meteorological data sources are 0.5° and 0.625° respectively.

RatedPower also offers various yearly fixed albedo options depending on the type of terrain of the site. These include:

- **MODIS BSA (default)** this value changes depending on the site
- **NASA_POWER_ALBEDO** this value changes depending on the site
- **A default (bare ground)** option with an albedo value of 0.2
- **Bare soil** with an albedo value of 0.17
- **Grass** with an albedo value of 0.25
- **Dry grass** with an albedo value of 0.3
- **Sand** with an albedo value of 0.36
- **White pebbles** with an albedo value of 0.58
- **Snow** with an albedo value of 0.65

An alternative option is to create an albedo data monthly or yearly profile by clicking on the "+" button to the left of the first card as shown in Figure 5.9.3.




Figure 5.9.3. Albedo data.

5.9.4. PV Module Losses

In this part, the user can choose the values for some of the main PV plant losses.

- **First Year PV Module Degradation:** losses caused by the degradation of the characteristics of the modules. This factor applies for the first year only.
- **Yearly PV Module Degradation:** losses caused by the degradation of the characteristics of the modules. This parameter reduces the energy production generated by the PV plant every year.
- **Soiling Losses:** losses caused by the formation of layers of dirt, dust, or snow on the surface of the PV modules. It can be set on a yearly or monthly basis. A separate soiling loss parameter is also available for bifacial modules.

- **Module Quality:** this can yield either a loss (when positive) or gain (when negative). It is due to the power tolerance guaranteed by the manufacturer.
- **Module Light-Induced Degradation (LID):** losses due to the degradation of the PV modules during the first few days after installation.
- **Mismatch:** the loss due to electrical mismatch between modules caused by the varying power of these modules.
- **Bifacial mismatch:** the loss caused by heterogeneous illumination of the back-face, usually due to the presence of a torque-beam. (Not to be confused with the near shading losses due to the torque beam)




Figure 5.9.4. PV modules losses.

5.9.5. PV Plant Losses

In this category, several losses can be set:

- **Plant auxiliary loss:** power consumption of the plant's auxiliary systems
- **Photovoltaic plant availability:** losses due to the unavailability of the PV plant due to maintenance or any other circumstances.
- **Grid availability:** losses due to the unavailability of the grid.

The user can also enable the inverter's auxiliary consumption losses for the primary and secondary inverter which are:

- **Auxiliary consumption:** consumption due to fans and other auxiliary equipment
- **Consumption threshold:** power value from which the auxiliary loss is applied
- **Night loss**

5.9.6. Advanced Configuration (Energy Tab)

The user can also modify the following parameters:

- **Constant heat transfer coefficient:** a parameter used to calculate the cell temperature of the PV module. It quantifies the heat dissipation between the module and the static air at ambient temperature. It is measured in W/m^2K .
- **Wind loss factor:** a parameter used to calculate the cell temperature of the PV module. It quantifies the additional heat dissipation produced by the air flow over the surface of the module. It is measured in W/m^2K .
- **Table transparency:** the percentage of how much light passes through the structure and the modules and illuminates the ground.

The user can also define the IAM loss model. In Figure 5.9.3, we can see the different models of IAM loss for both the front-face and the back-face (in the case of bifacial modules) of PV modules.

- **Manufacturer IAM profile:** this profile is taken directly from the PAN file.
- **ASHRAE model:** uses an incidence angle modifier coefficient of 0.05.
- **Air-glass model:** uses the index of refraction of normal glass of 1.526.
- **Air-glass model (AR coating):** uses the index of refraction of glass with an anti-reflective coating of 1.3.

IAM loss model

Front-face

Manufacturer IAM profile ^
ASHRAE model
Air Glass model
Air Glass model (AR coating)

Back-face

Air Glass model v

Figure 5.9.6. Front and back face IAM loss models.

Finally, the user can modify the time shift. It's a parameter used in the calculation of the solar position. It represents an offset in minutes from the reference time at which the solar position is calculated normally (middle point of the hourly or sub-hourly intervals).

5.10. Financial Tab

In this tab, users can select different cost templates which will be connected to all accounted entries of the Bill of Quantities (BOQ). Also, after defining a yearly OPEX and an energy selling profile, the pv plant revenue will be calculated and therefore a complete financial analysis will be carried out.

By default, RatedPower uses predefined price sheets from our public repository depending on the region of your site. All these public CAPEX templates come from IRENA (International Renewable Energy Agency) for different years as well as for more than 30 countries. They can be easily cloned and make any changes if necessary.

Users can either select to use the default CAPEX sheets or create their own ones, adding their internal prices and disabling any entry which they are not interested in. Both public and private templates will be stored on the CAPEX Template bar on the left side menu.




Figure 5.10.1. RatedPower's library of CAPEX templates.

While creating or cloning a CAPEX sheet, users can select between 18 different currencies: USD (\$), EUR (€), AUD (\$), BRL (R\$), CAD (\$), CLP (\$), CNY (¥), COP (Col\$), CZK (Kč), GBP (£), INR (₹), JPY (¥), MXN (\$), MZM (MTn), PLN (zł), RON (L), SEK (kr), ZAR (R). They can also set the price per unit as well as different taxes.

Sheet name Spain Currency USD Country Spain Folder IRENA - USD 2022

^ Hardware			
^ MAIN EQUIPMENT			
	Unit	Price / unit	Tax
Module	Main peak power (kWp) ▾	284.4 (US\$)	0 %
Inverter	Main peak power (kWp) ▾	38.9 (US\$)	0 %
^ BOS HARDWARE			
	Unit	Price / unit	Tax
Racking and mounting	Main peak power (kWp) ▾	90.6 (US\$)	0 %
Grid Connection	Main peak power (kWp) ▾	43.5 (US\$)	0 %
Cabling / Wiring	Main peak power (kWp) ▾	61.5 (US\$)	0 %
Safety and security	Main peak power (kWp) ▾	10 (US\$)	0 %
Monitoring and control	Main peak power (kWp) ▾	10.4 (US\$)	0 %

Figure 5.10.2. RatedPower’s CAPEX tool.


After having selected a CAPEX template to be working with, the user can also define an annual OPEX for each iteration they run. Within combined with the discount rate, RatedPower will provide economical results such as the pv plant total investment, it’s specific prices and the LCOE.

^ Financial		
Total price	Specific price	LCOE
<input type="text"/>	<input type="text"/>	<input type="text"/>

Figure 5.10.3. RatedPower’s Financial results.

Additionally, RatedPower will also provide a complete financial report. To do so, apart from using the previously defined CAPEX template, the yearly OPEX and the discount rate, users will also need to provide an energy selling profile in order to get the pv plant revenue.

Users can either select between a “Fixed price” for the energy selling (having the same price for the hourly production, with an escalation factor) or going for a “Variable price” for a better assessment of their pv plant profitability.



Revenue How to

Fixed price

 Variable price

Energy Price €/MWp

Escalation Factor %

Figure 5.10.4. RatedPower's Energy price profiles.

By selecting a "Variable price" profile, three different options will be appearing to let the user upload their specific price profiles for the pv plant financial assessment:



Energy prices ×

Prices models -

How to upload your

- 12 months x 24 hours
- 8760 hours
- 8760 hours x 50 years

Drag a file here or [browse](#)

Supports: .csv

Figure 5.10.5. RatedPower's 3 different variable price profiles.

1. 12 months x 24 hours: Users can define hourly prices for a representative day of each month.
2. 8760 hours: Users can define hourly prices for the first year of the pv plant lifetime.
3. 8760 hours x 50 years: Users can define hourly prices for the entire lifetime of the pv plant.

Once a revenue profile has been defined, by clicking on 'Show more/less' you will see all the different revenue profiles that were previously uploaded to the project. Users will be able to switch between all of them in further simulations.




Figure 5.10.6. RatedPower's stored price profiles.

Finally, clicking over each price profile on 'show details', the card will be expanded with more detailed information about pricing.



Figure 5.10.6. RatedPower's detailed price profile info.

- Maximum: First year maximum energy selling price.
- Minimum: First year minimum energy selling price.
- Average: First year average energy selling price.
- Spread (First year average daily spread): The first-year average of the differences between the maximum and minimum daily prices.

Finally, with the CAPEX template, the annual OPEX and the energy selling profile already defined, the calculation model will take all this info into consideration to carry out a complete financial analysis

document. All the financial parameters calculated in this model such as Cash Flows, NPV, IRR, Payback and ROI among others (you can find the corresponding glossary at the end of this section) are listed below:

Levelized Cost of Energy (LCOE)

The levelized cost of energy is the relation between the total cost of producing the energy plant and its energy output, and it is calculated following the formulas shown below.

$$LCOE_{year} = \frac{CAPEX + \sum_{year=1}^n \frac{OPEX_{year}}{(1+r)^{year}}}{\sum_{year=1}^n \frac{Energy_{year}}{(1+r)^{year}}}$$

Yearly “Free Cash Flow (FCF)”

Free cash flow (FCF) is the money a company has left over after paying its operating expenses (OPEX) and capital expenditures (CAPEX).

$$FCF_{year} = Revenue_{year} - CAPEX_{year} - OPEX_{year}$$

Yearly “Cumulative Free Cash Flow (CFCF)”

Cumulative Free Cash Flow (CFCF) is calculated by adding up all the Free Cash Flow (FCF) since the inception of the PV project.

$$CFCF_{year=0} = FCF_{year=0} = -CAPEX_{year=0}$$

$$CFCF_{year} = FCF_{year} + CFCF_{year-1}$$

Yearly “Discounted Free Cash Flow (DFCF)”

Discounted Free Cash Flow (DFCF) is the present value of the Free Cash Flows (FCF).

$$DFCF_{year} = \frac{FCF_{year}}{(1+r)^{year}}$$

Yearly “Discounted Cumulative Free Cash Flow (DCFCF)”

Discounted Cumulative Free Cash Flow (DCFCF) is the present value of the Cumulative Free Cash Flow (CFCF).

$$DCFCF_{year} = \frac{CFCF_{year}}{(1+r)^{year}}$$

Net Present Value (NPV)

The net present value (NPV) of a PV plant is the difference between the present value of the revenue from selling the energy produced and the present value of all the operating costs over a certain period of time.

$$NPV_{year} = -CAPEX + \sum_{year=1}^n \frac{(Revenue_{year} - OPEX_{year})}{(1+r)^{year}}$$

$$NPV_{year} = \sum_{year=0}^n \frac{FCF_{year}}{(1+r)^{year}}$$

$$NPV_{year} = \sum_{year=0}^n DFCF_{year}$$

$$NPV_{year} = DCFCF_{year}$$

Internal Rate of Return (IRR)

The Internal Rate of Return (IRR) is a financial indicator used to measure the profitability of a potential investment. IRR reflects the discount rate that makes the net present value (NPV) equal to zero for a given period of time.

$$0 = -CAPEX + \sum_{year=1}^n \frac{(Revenue_{year} - OPEX_{year})}{(1 + IRR_{year})^{year}}$$

$$0 = \sum_{year=1}^n \frac{FCF_{year}}{(1 + IRR_{year})^{year}}$$

Payback Period

The Discounted Payback Period refers to the number of years it takes to recover the initial investment (CAPEX), discounting future cash flows and taking into account the time value of money.

The following inequations system must be verified:

$$CAPEX > \sum_{year=1}^{Payback\ year-1} Revenue_{year} - OPEX_{year}$$

$$CAPEX \leq \sum_{year=1}^{Payback\ year} Revenue_{year} - OPEX_{year}$$

Discounted Payback Period

The Payback Period refers to the number of years it takes to recover the initial investment (CAPEX) of the PV plant.

The year in which this initial investment is recovered must verify the following inequations system:

$$CAPEX < \sum_{year=1}^{Disc.Payback} \frac{(Revenue_{year} - OPEX_{year})}{(1+r)^{year}}$$

$$CAPEX > \sum_{year=1}^{Disc.Payback-1} \frac{(Revenue_{year} - OPEX_{year})}{(1+r)^{year}}$$

Return on Investment (ROI)

Return on Investment (ROI) is a ratio that reflects the return on the PV plant's net income from the energy selling over a period of time versus the costs for the initial investment (CAPEX) and operation and maintenance (OPEX) throughout its lifetime.

$$ROI_{year} = \frac{-CAPEX + \sum_{year=1}^n (Revenue_{year} - OPEX_{year})}{CAPEX}$$

$$ROI_{year} = \frac{CFCF_{year}}{CAPEX}$$

Glossary:

- *CAPEX*: is the capital expenditure. It refers to the investment cost required to develop the project.
- *OPEX_{year}*: stands for operating expenses. It refers to the cost required to make sure that the pv plant is working properly throughout its entire lifetime. It includes the fixed operating costs introduced by the user [m.u/MWp] as well as the purchase costs for the nighttime consumed energy [m.u/MWh consumed].
- *Energy_{year}*: is the annual energy injected to the grid produced by the photovoltaic plant.
- *Revenue_{year}*: It refers to is the money generated from PV plant operation
- *r*: is the discount rate
- *n*: is the total number of operation years. This parameter reflects the lifetime of the PV plant.

5.11. Settings tab

The Settings tab is where the user can define the name of the design as well as adding notes. In the documentation settings, the languages and the unit system can be chosen.




Figure 5.11.1. Design and documentation settings

Finally, if the user is working on a project for a client, they can add the client's name and logo.




Figure 5.11.2. Client's name and logo setting

6. Simulation procedure

Once the parameters are selected by the user, the software starts to design and optimize the PV design following these steps:

1. **The layout of the modules and structures.** The first step is to draw multiple positions of structures and roads in order to maximize the power of the project. Once the software finds the best option, the position of the modules and structures is defined. This takes into account an additional safety distance between the fences and the PV modules.
2. **The layout of the electrical equipment.** Based on the electrical equipment defined by the user, the software will define the blocks that best fit the configuration for each inverter, string box, or DC bus. It locates these elements in the optimum position.
3. **The layout and definition of cables and trenches.** Cables and trenches are laid down based on the positions of the electrical equipment defined in Step 2. The algorithm tries to find the shortest path to minimize cable length. After that, all cables are sized based on either the IEC or the NEC electrical standard. More information on this topic is available in our [Electrical Methodology](#).
4. **Energy Yield.** Once all the elements of the layout are defined, the software calculates the energy yield production of the PV plant. More information regarding how these calculations are done, can be found in our [Energy Yield Methodology](#).
5. **Documentation.** The final step is to generate all the documents and drawings needed for requesting the proposal of the project.

6.1. Batch design tool

The user can choose to create one design or generate up to 10 different designs simultaneously using the Batch Design tool available by clicking the arrow next to the “Run Design” button.




Figure 6.1.1. “Run batch” button

There are three batch design options, allowing the user to vary either the Pitch distance, the DC/AC Ratio or the Tilt angles.

- **Pitch distance:** Starting from the minimum value of the distance between structures (indicated as 'Min. Pitch distance'), **RatedPower** will simulate up to 10 versions of the design. Each version will be assigned a pitch value higher than the previous one by the increment ('Pitch distance step value') defined.

Generate multiple designs ⓘ
✕

Pitch distance ⓘ

DC / AC Ratio ⓘ

Tilt angles ⓘ

Min. Pitch distance meters
Min: 3.94 m

Pitch distance step value meters

Max. Pitch distance meters
Max: 15.10 m

Designs data table ↻ Refresh data table

<input checked="" type="checkbox"/> Designs	Pitch distance	Clearance distance	GCR
<input checked="" type="checkbox"/> Biarritz_9_1	<input type="text" value="13.30"/> meters	<input type="text" value="9.36"/> meters	<input type="text" value="29.60"/> %
<input checked="" type="checkbox"/> Biarritz_9_2	<input type="text" value="13.50"/> meters	<input type="text" value="9.56"/> meters	<input type="text" value="29.16"/> %
<input checked="" type="checkbox"/> Biarritz_9_3	<input type="text" value="13.70"/> meters	<input type="text" value="9.76"/> meters	<input type="text" value="28.74"/> %
<input checked="" type="checkbox"/> Biarritz_9_4	<input type="text" value="13.90"/> meters	<input type="text" value="9.96"/> meters	<input type="text" value="28.33"/> %
<input checked="" type="checkbox"/> Biarritz_9_5	<input type="text" value="14.10"/> meters	<input type="text" value="10.16"/> meters	<input type="text" value="27.92"/> %
<input checked="" type="checkbox"/> Biarritz_9_6	<input type="text" value="14.30"/> meters	<input type="text" value="10.36"/> meters	<input type="text" value="27.53"/> %
<input checked="" type="checkbox"/> Biarritz_9_7	<input type="text" value="14.50"/> meters	<input type="text" value="10.56"/> meters	<input type="text" value="27.15"/> %
<input checked="" type="checkbox"/> Biarritz_9_8	<input type="text" value="14.70"/> meters	<input type="text" value="10.76"/> meters	<input type="text" value="26.78"/> %
<input checked="" type="checkbox"/> Biarritz_9_9	<input type="text" value="14.90"/> meters	<input type="text" value="10.96"/> meters	<input type="text" value="26.42"/> %

Cancel Generate designs

Figure 6.1.2. Batch design's pitch distance option

- **DC/AC ratio:** This tool allows the user to simulate up to 10 designs with different DC/AC ratios. The first design will have the minimum DC/AC ratio defined by the user, while the subsequent designs will have a higher DC/AC ratio than their precedent one by the increment value (the step value). The user can choose specific capacity or maximum capacity.

Generate multiple designs ⓘ
✕

Pitch distance ⓘ

DC / AC Ratio ⓘ

Tilt angles ⓘ

Specif. capacity

Max. capacity

Primary inverters amount inverters

Rated power (approx.) MWac

Minimum DC / AC Ratio

DC / AC Ratio step value

Maximum DC / AC Ratio

Designs data table
↻ Refresh data table

<input checked="" type="checkbox"/> Designs	Rated power	DC / AC Ratio		Peak power	
<input checked="" type="checkbox"/> Biarritz_9_1	115.5 MWac	<input style="width: 80%;" type="text" value="1.20"/>	< >	<input style="width: 80%;" type="text" value="138.60"/>	MWdc
<input checked="" type="checkbox"/> Biarritz_9_2	115.5 MWac	<input style="width: 80%;" type="text" value="1.21"/>	< >	<input style="width: 80%;" type="text" value="139.75"/>	MWdc
<input checked="" type="checkbox"/> Biarritz_9_3	115.5 MWac	<input style="width: 80%;" type="text" value="1.22"/>	< >	<input style="width: 80%;" type="text" value="140.91"/>	MWdc
<input checked="" type="checkbox"/> Biarritz_9_4	115.5 MWac	<input style="width: 80%;" type="text" value="1.23"/>	< >	<input style="width: 80%;" type="text" value="142.06"/>	MWdc
<input checked="" type="checkbox"/> Biarritz_9_5	115.5 MWac	<input style="width: 80%;" type="text" value="1.24"/>	< >	<input style="width: 80%;" type="text" value="143.22"/>	MWdc
<input checked="" type="checkbox"/> Biarritz_9_6	115.5 MWac	<input style="width: 80%;" type="text" value="1.25"/>	< >	<input style="width: 80%;" type="text" value="144.38"/>	MWdc
<input checked="" type="checkbox"/> Biarritz_9_7	115.5 MWac	<input style="width: 80%;" type="text" value="1.26"/>	< >	<input style="width: 80%;" type="text" value="145.53"/>	MWdc

Cancel
Generate designs

Figure 6.1.3. Batch design's DC/AC ratio option

- **Tilt angle:** For fixed structures the user can generate up to 10 designs while varying the Tilt angles. The first design will have the tilt angle that the user set for the original design while the subsequent designs will have a higher tilt angle than their precedent one by the increment value (the step value). The user can change the angle step value or change the max tilt angle to acquire a set of wanted angles. As the tilt angle is intertwined with pitch distance, the user can choose to vary both at the same time or keep the same pitch distance for all tilt angles.

Generate multiple designs ⓘ ✕

Pitch distance ⓘ DC / AC Ratio ⓘ **Tilt angles ⓘ**

Min. tilt angle ° Min: 0° Tilt angle step value ° Max. tilt angle ° Max: 80°

Pitch distance options:
 Same pitch distance for all tilt angles meters
 Different pitch distances for each tilt angle

Designs data table

<input checked="" type="checkbox"/> Designs	Tilt angle (°)	Pitch distance
<input checked="" type="checkbox"/> Biarritz_9_1	<input type="text" value="37"/> ° < >	<input type="text" value="13.30"/> meters <small>Min: 3.94m</small>
<input checked="" type="checkbox"/> Biarritz_9_2	<input type="text" value="38"/> ° < >	<input type="text" value="13.30"/> meters <small>Min: 3.88m</small>
<input checked="" type="checkbox"/> Biarritz_9_3	<input type="text" value="39"/> ° < >	<input type="text" value="13.30"/> meters <small>Min: 3.83m</small>
<input checked="" type="checkbox"/> Biarritz_9_4	<input type="text" value="40"/> ° < >	<input type="text" value="13.30"/> meters <small>Min: 3.78m</small>
<input checked="" type="checkbox"/> Biarritz_9_5	<input type="text" value="41"/> ° < >	<input type="text" value="13.30"/> meters <small>Min: 3.72m</small>

Figure 6.1.4. Batch design's tilt angle options

7. Simulation results

Once the design is generated the user can open it, and there he will see three main tabs. Results are displayed in the Overview followed by the Energy and the Configuration. The user can also have a 3D view of their design in the last tab

The Overview tab contains the final layout of the PV plant. Components such as structures, cables, trenches, power stations, roads, OHL and others can be seen. It provides general information about the system including important metrics as shown in the blue box below.



Figure 7.1. Simulation overview.

The Energy tab provides comprehensive details on the energy yield, solar resource, albedo, horizon, as well as the system's losses and gains for the initial year.




Figure 7.2. Energy results.

The following tab contains the configuration details, encompassing information on the equipment, electrical aspects, and civil specifications of the PV plant.




Figure 7.3. Configuration information.

Finally, on the last tab, we have the 3D view of the PV plant.




Figure 7.4. 3D View.

8. Documentation

Once the design is completed, supporting documentation related to the design is generated. The documentation generated consists of reports, spreadsheets, and drawings. It is important to mention that the generated CAD files for the layout and slopes are georeferenced.

Documents

- Design Report (DOCX, PDF)
- Energy Yield Report (DOCX, PDF)
- Interconnection Facility Report (DOCX, PDF)
- BESS Design Report (DOCX, PDF)
- Overhead line report (DOCX, PDF)

Spreadsheets

- Project Sheet (XLSX)
- Bill of Quantities (XLSX)
- Financial Analysis (XLSX)
- Energy Yield Results (XLSX)
- Listing of Cables (XLSX)
- Listing of Posts (XLSX)
- Terrain XYZ (CSV)
- Power flow model (XLSX)

Drawings

- General layout (PDF, DXF, KML)
- Layout 3D (DWG)
- 3D scene (PVC) (ZIP)
- MV Single Line Diagrams (PDF, DXF)
- LV Single Line Diagrams (PDF, DXF)
- MV-LV Single Line Diagrams (PDF, DXF)
- Topography Analysis (Terrain slopes) (PDF, DXF, KML)
- Structure Profiles (ZIP)
- Interconnection Facility SLD (PDF, DXF)
- Interconnection Facility Layout (PDF, DXF)
- BESS General Layout (PDF, DXF, KML)
- BESS MVLV SLD (PDF, DXF)
- Overhead line layout PDF, DXF)

8.1. Documents

8.1.1. Design Report

The design report is a document that describes the site location, topography, solar resource, equipment, and configuration of the whole project. It is generated in both PDF and Word formats.

5. PV PLANT SIZING

5.1. Electrical configuration

The photovoltaic generator array consists of photovoltaic modules connected in serial and parallel associations. This configuration is defined by the module and inverter technical features, the power system requirements, and the meteorological conditions of the specific location in El Salvador.

The methodology used to define the electrical configuration consists of sizing the strings of modules, electrical junction boxes (if present), wiring and inverters to find an electrical configuration that satisfies the DC/AC ratio goal. Some of the design criteria considered were:

- Reaching the maximum DC voltage possible, staying below the maximum rated voltage of the photovoltaic modules, 1500 V. This is done to minimize the DC power transmission losses.
- The photovoltaic generator array (DC field) is oversized with respect to the rated power of the AC system, to maximize the energy yield.

The main features of the electrical configuration are shown in Table 13.

Table 13. Electrical configuration characteristics

Electrical configuration characteristics	
Plant rated power	28.6 MW _{ac}
Plant peak power	34.3 MW _{dc}
DC/AC Ratio	1.20
Modules per string	21

The medium voltage network connecting the power stations to the substation operates at 20.0 kV. It is composed of 2 medium voltage branches.

Figure 8.1.1. Design report.

8.1.2. Energy Yield Report

Its purpose is to describe the methodology used to compute the energy yield of the PV plant and to present the results obtained. It is generated in both PDF and Word formats.

Description	Value	Unit	Loss
Solar resource			
Global horizontal irradiance	2197.3	kWh/m2	
Transposition to the plane of array	2883.0	kWh/m2	+31.21 %
Far shadings (horizon profile)	2883.0	kWh/m2	0.00 %
Near shadings	2826.4	kWh/m2	-1.96 %
IAM loss	2769.6	kWh/m2	-2.01 %
Soiling	2714.2	kWh/m2	-2.00 %
Global effective irradiance	2714.2	kWh/m2	
Photovoltaic conversion (nominal efficiency)			
Total receptive surface	651384	m2	
Total solar energy at the plane of array	1768.0	GWh	
STC photovoltaic module efficiency	18.52	%	
Energy with STC conversion efficiency	327.4	GWh	
Photovoltaic module losses			
Module degradation	326.9	GWh	-0.30 %
Irradiance level loss	326.9	GWh	+0.03 %
Temperature loss	301.2	GWh	-7.91 %
Quality	303.3	GWh	+0.70 %
LID (Light Induced Degradation)	297.2	GWh	-2.00 %
Electrical mismatch	294.2	GWh	-1.00 %
Shading mismatch	294.2	GWh	0.00 %
DC cable losses	290.4	GWh	-1.31 %
Energy at the inverter input	290.4	GWh	
Inverter DC to AC conversion			
Conversion efficiency loss	285.3	GWh	-1.74 %
Loss due to the inverter output power limit	280.2	GWh	-1.81 %
Loss due to the inverter input power threshold	280.2	GWh	0.00 %
Loss due to the inverter maximum input voltage limit	280.2	GWh	0.00 %
Loss due to the inverter input voltage threshold	280.2	GWh	0.00 %
Auxiliary consumption	280.2	GWh	0.00 %
Energy available at the inverter output	280.2	GWh	

Figure 8.1.2. Example of energy yield report.

8.1.3. Interconnection Facility Report

Its purpose is to describe the interconnection facility, and everything related to the MV and the HV systems. It is generated in both PDF and Word formats.

4. GENERAL CONSIDERATIONS OF THE SUBSTATION

4.1. Environmental conditions

Environmental conditions are shown in Table 6. They have been used to calculate some of the substation’s key features such as the type of insulators, the size of the buses or the value of the loads.

Table 6. The environmental conditions of the site

Environmental conditions	
Altitude	-5 m a.s.l.
Maximum temperature	31.0 °C
Average temperature	10.9 °C
Minimum temperature	-5.5 °C
Pollution level	Medium
Specific creepage distance	30 mm/kV
Maximum wind speed	120 km/h
Air pressure	70 daN/m

4.2. Short-circuit current

The short-circuit levels that have been considered in the design of the electrical substation are shown in Table 7.

Table 7. The short-circuit levels

Nominal system voltages	Short-circuit levels
132.0 kV	40.0 kA
20.0 kV	25.0 kA

4.3. Insulation coordination

Figure 8.1.3. Example of the interconnection facility report.

8.1.4. BESS Design Report

The BESS design report is a document that describes the site location, the equipment, and sizing of the BESS. It is generated in both PDF and Word formats.

4. BESS SIZING

4.1. Electrical configuration

The methodology used to define the BESS power requirement consists of sizing the battery containers to find a configuration that satisfies the power supply duration goal.

The main features of the electrical configuration are shown in Table 10.

Table 10. BESS configuration characteristics

Electrical configuration characteristics	
BESS rated power	6.0 MW
BESS installed energy	12.0 MWh
Power supply duration	2.00 h

The medium voltage network connecting the power conversion systems to the substation operates at 20 kV. It is composed of 2 medium voltage branches.

4.2. Electrical Cabling Design

The goal when calculating the characteristics of the electrical wiring is to minimize the cable lengths and sections. The sections are selected according to IEC 60502-2 standard.

When selecting a cable cross section, the current carrying capacity, the voltage drop, and the short circuit current were considered. The maximum allowed voltage drop was 0.50% for the AC cables of the MV network.

A summary of the selected cable sections and their installation method is shown in Table 11.

Table 11. Summary of the selected cable sections

Section	Conducting material	Insulating material	Installation type
150 mm ²	Al	XLPE	Buried in trench

4.3. Civil works

Some of the parameters considered for the civil works required to build the BESS are shown in Table 12.

Table 12. Civil works

Civil works	
Distance face to face between BESS	4.0 m

Figure 8.1.4. Example of the BESS design report.

8.1.5. Overhead Line Report

The OHL or Gen-tie report is a document that describes the site location, line characteristics, electrical and mechanical calculations, and tower geometry. It is generated in both PDF and Word formats.

3. DESCRIPTION OF THE OVERHEAD LINE

The general characteristics of the 115.0kV overhead line are shown in Table 3:

Table 3. The overhead line general characteristics

Line characteristics	
Nominal system voltage	115.0 kV
System highest voltage	123.0 kV
Capacity	201.6 MVA
Frequency	60 Hz
Length	11729.97 ft
Overhead line type	transmission
Circuit arrangement	Simplex
Sub-conductor number	2
Number of earth wires	1
Phase conductor type	160-A1/S1A
Suspension insulator type	long rod
Tension insulator type	long rod
Tower type	HV S tower
Number of towers	36

In total, 36 towers will carry the transmission conductors to the point of the interconnection. The coordinates of each tower in UTM are listed in Table 4:

Table 4. The towers' coordinates.

Tower	X	Y	Z
Tower 1	517233.037	4621126.282	1671.741
Tower 2	517233.176	4621068.24	1671.714
Tower 3	517031.256	4621070.446	1671.249
Tower 4	516887.027	4621072.021	1669.379
Tower 5	516752.414	4621073.492	1668.513
Tower 6	516575.789	4621033.048	1659.135
Tower 7	516399.164	4620992.604	1653.012
Tower 8	516281.002	4621027.652	1653.439

Figure 8.1.5. Example of the OHL report.

8.2. Spreadsheets

8.2.1. Project Sheet

The project sheet consists of a one-page summary of site characteristics, equipment, and configuration of the PV project. It is generated in Excel format.




Figure 8.2.1. Project sheet.

8.2.2. Bill of Quantities

The bill of quantities consists of a detailed list of main equipment, civil works, electrical equipment, and some miscellaneous items and is needed for requesting the proposal. It is generated in Excel format. Additional information regarding the different entries of the BOQ can be found in the [BOQ Methodology](#).

Project		pvDesign Demo Project	
Design		pvDesign Demo Design	
		Date 2021/08/04	
Item		Unit	Quantity
1 MAIN EQUIPMENT			
1.1	PV module		
1.1.1	Trina Solar - TSM-550DEG19C.20 (550 W bifacial Si-mono). Dimensions 2384.0 mm x 10	Unit	170316
1.2	Structure		
1.2.1	Horizontal single axis tracker: JuTracker - BiT-2H (2H)	Unit	6308
1.3	Inverter		
1.3.1	Sungrow - SG250HX-IN (250 kVA)	Unit	310
1.4	Power Station		
1.4.1	Power Station up to 2000 kVA, 1.203 dc/ac ratio	Unit	23
1.4.2	Power Station up to 2000 kVA, 1.188 dc/ac ratio	Unit	5
1.4.3	Power Station up to 2000 kVA, 1.218 dc/ac ratio	Unit	3
1.4.4	Power Station up to 2000 kVA, 1.203 dc/ac ratio	Unit	2
1.4.5	Power Station up to 1750 kVA, 1.205 dc/ac ratio	Unit	1
1.4.6	Power Station up to 500 kVA, 1.188 dc/ac ratio	Unit	1
1.4.7	Power Station up to 2000 kVA, 1.195 dc/ac ratio	Unit	1
1.4.8	Power Station up to 1500 kVA, 1.346 dc/ac ratio	Unit	1
1.4.9	Power Station up to 1250 kVA, 1.212 dc/ac ratio	Unit	1
1.4.10	Power Station up to 1500 kVA, 1.208 dc/ac ratio	Unit	1
1.4.11	Power Station up to 2000 kVA, 1.210 dc/ac ratio	Unit	1
1.4.12	Power Station up to 1000 kVA, 1.485 dc/ac ratio	Unit	1
2 CIVIL WORKS			
2.1	Site Conditions		
2.1.1	Clearing and grubbing	m2	1478709.83
2.1.2	Topsoil and vegetation removal	m3	295741.97
2.1.3	Internal roads (4.0 m width)	m	11242.73
2.1.4	Road ditches (Optional)	m	11242.73
2.2	Earth works		
2.2.1	Total earth works fill volume	m3	3943.03
2.2.2	Total earth works cut volume	m3	3853.11
2.3	Foundations		
2.3.1	Power Station foundation	Unit	41
2.3.2	Structure Poles	Unit	31745
2.4	Trenches and manholes		

Figure 8.2.2. Example of Bill of Quantities.

8.2.3. Financial Analysis

The financial analysis consists of a detailed document where all the units and prices of all the entries selected in the Cost bar are shown. The quantities of these units are also used to calculate the CAPEX of the design.

Item	Reference unit	Amount	Unit	Unitary price	Pre-tax price	Taxes	Final price
1 MAIN EQUIPMENT							
1.1 DC Side							
1.1.1 PV module	Number of PV modules	170,316.00	modules	0.00 \$/modules	100.00 \$	0%	100.00 \$
1.1.2 Structures	Main peak power	93,674.00	kWp	0.00 \$/kWp	150.00 \$	0%	150.00 \$
1.2 AC Side							
1.2.1 Power stations	Number of power stations	41.00	ps	0.00 \$/ps	30,000.00 \$	0%	30,000.00 \$
1.2.2 Primary inverter	Number of primary inverters	310.00	inverters	0.00 \$/inverters	122.00 \$	0%	122.00 \$
2 CIVIL WORKS							
2.1 Site Conditions							
2.1.1 Total earth works fill volume	Earthworks fill volume	3,943.03	m³	0.00 \$/m³	1.00 \$	0%	1.00 \$
2.1.2 Total earth works cut volume	Earthworks cut volume	3,853.11	m³	0.00 \$/m³	3.00 \$	0%	3.00 \$
2.1.3 Clearing and grubbing	Fence area	1,478,709.83	m²	0.00 \$/m²	3.00 \$	0%	3.00 \$
2.1.4 Topsoil and vegetation removal	Removal area	295,741.97	m²	0.00 \$/m²	4.00 \$	0%	4.00 \$
2.1.5 Internal roads	Roads length	11,242.73	m	0.00 \$/m	5.00 \$	0%	5.00 \$
2.1.6 Road ditches	Road ditches length	11,242.73	m	0.00 \$/m	5.00 \$	0%	5.00 \$
2.2 Foundations							
2.2.1 Power Station foundation	Number foundations PS	41.00	foundations	0.00 \$/foundations	1.00 \$	0%	1.00 \$
2.2.2 Structure Poles Op.1 - Driving into the ground	Number foundations structure	31,745.00	foundations	0.00 \$/foundations	2.00 \$	0%	2.00 \$
2.2.3 Structure Poles Op.2 - Pre-drilling and Driving	Number foundations structure	31,745.00	foundations	0.00 \$/foundations	3.00 \$	0%	3.00 \$
2.2.4 Structure Poles Op.3 - Screwing into the ground	Number foundations structure	31,745.00	foundations	0.00 \$/foundations	4.00 \$	0%	4.00 \$
2.2.5 Structure Poles Op.4 - Pre-drilling + Screwing	Number foundations structure	31,745.00	foundations	0.00 \$/foundations	5.00 \$	0%	5.00 \$
2.2.6 Structure Poles Op.5 - Concrete foundation	Number foundations structure	31,745.00	foundations	0.00 \$/foundations	5.00 \$	0%	5.00 \$
2.3 Trenches and manholes							
2.3.1 Low Voltage manholes	Number LV manholes	476.00	manholes	0.00 \$/manholes	0.00 \$	0%	0.00 \$
2.3.2 Medium Voltage manholes	Number MV manholes	326.00	manholes	0.00 \$/manholes	0.00 \$	0%	0.00 \$
2.3.3 Trench 400mm x 1000mm	Lv trenches	7,893.26	m³	0.00 \$/m³	0.00 \$	0%	0.00 \$
	Mv trenches	3,566.37	m³	0.00 \$/m³	0.00 \$	0%	0.00 \$
2.3.4 Trench 800mm x 1000mm	Lv trenches	0.00	m³	0.00 \$/m³	0.00 \$	0%	0.00 \$
2.3.5 Trench 800mm x 1500mm	Mv trenches	6,209.60	m³	0.00 \$/m³	0.00 \$	0%	0.00 \$
2.3.6 Trench 800mm x 2000mm	Mv trenches	307.02	m³	0.00 \$/m³	0.00 \$	0%	0.00 \$
2.3.7 Earthing trenches	Earthing trenches vol	306.82	m³	0.00 \$/m³	0.00 \$	0%	0.00 \$

Figure 8.2.3. Example of Financial Analysis.

8.2.4. Energy Yield Results

It shows a summary of the PV plant’s production and different system losses. It also accurately shows the hourly production during the whole lifetime of the plant. It is generated in Excel format. For additional information regarding the energy calculation, please check our [Energy Yield Methodology](#).

HOURLY ENERGY PRODUCTION AND METEO DATA					pvDesign	
METEOROLOGICAL DATA				ENERGY PRODUCTION		
Global Horizontal Irradiance (GHI)	Beam Horizontal Irradiance (BHI)	Diffuse Horizontal Irradiance (DHI)	Air temperature	Year 1	Year 2	
[kW/m ²]	[kW/m ²]	[kW/m ²]	[°C]	MWh	MWh	
0,0	0,0	0,0	27,3	0,0	0,0	
0,0	0,0	0,0	27,2	0,0	0,0	
0,0	0,0	0,0	27,2	0,0	0,0	
0,0	0,0	0,0	27,2	0,0	0,0	
0,0	0,0	0,0	27,2	0,0	0,0	
0,0	0,0	0,0	27,2	0,0	0,0	
0,0	0,0	0,0	27,4	0,0	0,0	
103,0	56,0	47,0	27,6	8,0	7,9	
328,0	248,0	80,0	27,9	23,2	23,1	
542,0	444,0	98,0	27,9	28,1	28,0	
712,0	602,0	110,0	27,8	30,0	30,0	
819,0	703,0	116,0	27,8	30,8	30,8	
853,0	735,0	118,0	27,8	30,9	30,8	
811,0	695,0	116,0	27,8	31,1	31,0	
698,0	589,0	109,0	27,7	31,3	31,2	
524,0	426,0	98,0	27,8	31,2	31,1	
310,0	231,0	79,0	27,8	25,4	25,3	
95,0	42,0	53,0	27,8	4,9	4,9	

Figure 8.2.4. Example of Energy Yield Results.

8.2.5. Listing of Cables

It shows a complete list of all the cables found in the layout divided into subsystems. It includes information like cable characteristics, power, voltage, current, and voltage drop throughout each cable. It is generated in Excel format. For additional information regarding the calculation process of the cross-sections of these cables, please check our [Electrical Yield Methodology](#).

Cable Size List										
Project Design		California		RatedPower						
Electrical Standard		11								
Electrical Configuration		IEC								
		String Box								
Dimensions		Cable Characteristics				Electrical Characteristics				
Wire cross section	Cable Length [m]	Installation Type	Material	Insulation	Repetitions	Rated Power [kVA]	Voltage [V]	Current [A]	Voltage Drop [V]	Voltage Drop [V %]
400	402.3	Trench	Al	XLPE	2	16366	20000	818.3	28.25	0.14
400	168	Trench	Al	XLPE	1	14028	20000	701.4	10.11	0.05
400	147	Trench	Al	XLPE	1	11690	20000	584.5	7.37	0.04
120	136.5	Trench	Al	XLPE	1	9352	20000	467.6	18.26	0.09
120	147	Trench	Al	XLPE	1	7014	20000	350.7	14.75	0.07
120	227.6	Trench	Al	XLPE	1	4676	20000	233.8	15.22	0.08
120	231	Trench	Al	XLPE	1	2338	20000	116.9	7.73	0.04
400	1837.9	Trench	Al	XLPE	2	16366	20000	818.3	129.07	0.65
400	385.1	Trench	Al	XLPE	1	14028	20000	701.4	23.18	0.12
400	206.6	Trench	Al	XLPE	1	11690	20000	584.5	10.36	0.05
120	189	Trench	Al	XLPE	1	9352	20000	467.6	25.28	0.13
120	238.1	Trench	Al	XLPE	1	7014	20000	350.7	23.88	0.12
120	189	Trench	Al	XLPE	1	4676	20000	233.8	12.64	0.06
120	190	Trench	Al	XLPE	1	2338	20000	116.9	6.36	0.03
400	970.6	Trench	Al	XLPE	2	16366	20000	818.3	68.16	0.34
400	199.5	Trench	Al	XLPE	1	14028	20000	701.4	12.01	0.06
400	269.6	Trench	Al	XLPE	1	11690	20000	584.5	13.52	0.07
400	147	Trench	Al	XLPE	1	9352	20000	467.6	5.9	0.03
120	217.1	Trench	Al	XLPE	1	7014	20000	350.7	21.78	0.11
120	262.5	Trench	Al	XLPE	1	4676	20000	233.8	17.56	0.09
120	301.1	Trench	Al	XLPE	1	2338	20000	116.9	10.07	0.05
400	556.3	Trench	Al	XLPE	2	16366	20000	818.3	39.07	0.2
400	168	Trench	Al	XLPE	1	14028	20000	701.4	10.11	0.05
400	301.1	Trench	Al	XLPE	1	11690	20000	584.5	15.1	0.08
120	252	Trench	Al	XLPE	1	9352	20000	467.6	33.71	0.17
120	332.6	Trench	Al	XLPE	1	7014	20000	350.7	33.36	0.17
120	168	Trench	Al	XLPE	1	4676	20000	233.8	11.24	0.06
120	238.1	Trench	Al	XLPE	1	2338	20000	116.9	7.96	0.04
400	1766.3	Trench	Al	XLPE	2	4676	20000	233.8	35.44	0.18

Figure 8.2.5. Example of Listing of Cables.

8.2.6. Listing of Posts

It shows a complete list of all the structures and posts found in the layout. It includes information like the locations, the slopes and other criteria. It is generated in Excel format.

Structures									
Project Design		California							
Structure manufacturer		1							
Structure model		Generic							
		Generic - 2V							
Structure unique identification code	Code		Location			Slopes			
	Power station	Block	Easting [m]	Northing [m]	Ground Elevation [m]	Row or axis direction [%]	Pitch direction [%]		
AA1-S280	PS1-1	AA1-B280	411609.89	4879906.9	56.64	1.56	0.29		
AA1-S313	PS1-1	AA1-B313	411616.67	4879896	56.69	1.78	0.61		
AA1-S314	PS1-1	AA1-B314	411623.75	4879906.71	56.87	2.02	0.39		
AA1-S315	PS1-1	AA1-B315	411616.96	4879917.6	56.79	1.78	0.42		
AA1-S316	PS1-1	AA1-B316	411624.04	4879928.31	56.99	2.37	0.33		
AA1-S348	PS1-1	AA1-B348	411637.32	4879884.93	57.1	3	1.71		
AA1-S349	PS1-1	AA1-B349	411630.53	4879895.82	56.96	2.72	0.89		
AA1-S350	PS1-1	AA1-B350	411637.61	4879906.52	57.21	2.55	0.4		
AA1-S351	PS1-1	AA1-B351	411630.82	4879917.42	57.06	2.91	0.46		
AA1-S352	PS1-1	AA1-B352	411637.89	4879928.12	57.45	3.73	0.46		
AA1-S353	PS1-1	AA1-B353	411631.11	4879939.01	57.11	4.27	1.47		
AA1-S354	PS1-1	AA1-B354	411638.18	4879949.72	57.38	4.7	2.24		
AA1-S386	PS1-1	AA1-B386	411644.1	4879874.03	57.18	3.02	1.26		
AA1-S387	PS1-1	AA1-B387	411651.18	4879884.74	57.45	3.35	1.18		
AA1-S388	PS1-1	AA1-B388	411644.39	4879895.63	57.39	2.57	0.89		
AA1-S389	PS1-1	AA1-B389	411651.46	4879906.34	57.56	2.3	0.47		
AA1-S390	PS1-1	AA1-B390	411644.68	4879917.23	57.58	3.16	0.76		
AA1-S391	PS1-1	AA1-B391	411651.75	4879927.94	57.93	4.02	1.2		
AA1-S392	PS1-1	AA1-B392	411644.97	4879938.83	57.85	4.32	1.47		
AA1-S424	PS1-1	AA1-B424	411657.96	4879873.85	57.7	4.72	1.34		
AA1-S425	PS1-1	AA1-B425	411655.02	4879884.55	58.04	4.11	0.84		

Figure 8.2.6. Example of Listing of Posts.

8.2.7. Terrain XYZ

This file shows the terrain elevation points of the site.

# Terrain elevation points for: Ratio DC AC PV Plant		
# Prepared for: Rated Power		
# Generation date: 2022/04/05		
# UTM Zone: 31N (EPSG code 32631)		
UTM_X	UTM_Y	Z
618184.8	5780115	-4.927
618184.8	5780116	-4.915
618184.8	5780117	-4.901
618184.8	5780118	-4.884
618184.8	5780119	-4.865
618184.8	5780120	-4.843
618184.8	5780121	-4.819
618184.8	5780122	-4.791
618184.8	5780123	-4.76
618184.8	5780124	-4.727
618184.8	5780125	-4.691
618184.8	5780126	-4.654
618184.8	5780127	-4.615
618184.8	5780128	-4.577

Figure 8.2.7. Example of Original terrain XYZ.

8.2.8. Power flow model

The Power Flow Model (PFM) document describes the flow of energy that occurs through the different parts of the PV plant, BESS, interconnection facility, and overhead lines (gen-tie).




Figure 8.2.8. Example of power flow model in xlsx format.

8.3. Drawings

8.3.1. General Layout

The general layout covers the main equipment, structures, roads, perimeter fences, DC and MV cabling, trenches, and substation location. Every item is divided into layers. It is generated in PDF, in CAD (DXF) and in KML.




Figure 8.3.1. Example of General Layout in CAD format.

8.3.2. Layout 3D

The layout 3D covers the structures, roads, power stations, available area location, and substation location. This file can be downloaded in CAD (DWG).




Figure 8.3.2. Example of Layout 3D in CAD format.

8.3.3. 3D scene (PVC)

This document is a .zip folder with one or more .PVC files. This document allows users to export the shading scene from **RatedPower** to PVsyst. Multiple files are generated only when the size of the PV plant is too big and results in one .PVC file being too heavy to export to PVsyst.

8.3.4. MV Single Line Diagram

The medium voltage single line diagram consists of a group of drawings that show the cabling and power station's main values for the medium voltage side. Drawings are generated in both PDF and CAD (DXF) formats.




Figure 8.3.4. Example of the MV single line diagram drawing.

8.3.5. LV Single Line Diagram

The low voltage single line diagram consists of a group of drawings that show the cabling and power station's main values for the low voltage side. Drawings are generated in both PDF and CAD (DXF) formats.




Figure 8.3.5.1. Example of the LV single line diagram drawing (String box).




Figure 8.3.5.2. Example of the LV single line diagram drawing (Inverter).




Figure 8.3.5.3. Example of the LV single line diagram drawing (Power Station).

8.3.6. MV-LV Single Line Diagrams

The medium and low voltage single line diagram consists of a group of drawings that show the cabling and power station's main values for both the low and medium voltage side. Drawings are generated in both PDF and CAD (DXF) formats.




Figure 8.3.6. Example of the MV-LV single line diagram drawing.

8.3.7. Topography Analysis (terrain slopes)

The topography analysis (terrain slopes) layout shows all the structures, posts and slopes of the terrain. It also marks any structures that exceed the topography criteria defined by the user. The slopes of the terrains are shown in four colors depending on the slope value: green (<5%), orange (5-10%), red (10-15%) and blue (>15%) by default, but these values can be changed by using the slider as we have mentioned earlier in this methodology. It is generated in PDF, in CAD (DXF) and in KML.




Figure 8.3.7. Example of the topography analysis (terrain slopes) layout.

8.3.8. Structure Profiles

The structure profiles layout shows different points of view of all the structures, their posts and the slopes of the terrain. Drawings are generated in CAD (DXF) format that are saved inside a zip file.




Figure 8.3.8. Example of the structure profiles CAD file.

8.3.9. Interconnection Facility SLD

The interconnection facility single line diagram shows the main components of the interconnection facility and their characteristics. Drawings are generated in both PDF and CAD (DXF) formats.




Figure 8.3.9. Example of the interconnection facility SLD drawing.

8.3.10. Interconnection Facility Layout

The interconnection facility layout shows two views of the plane of the substation. Drawings are generated in both PDF and CAD (DXF) formats.




Figure 8.3.10. Example of the interconnection facility layout.

8.3.11. BESS General Layout

The BESS layout covers the battery containers, PCS, MV cabling, trenches, and fence location. It is generated in PDF, in CAD (DXF) and in KML.




Figure 8.3.11. Example of the BESS layout.

8.3.12. BESS MV-LV Single Line Diagram

The BESS MV-LV single line diagram shows the main components of the BESS system, including the battery containers, racks, inverters, MV and LV lines, and other relevant electrical equipment. Drawings are generated in both PDF and in CAD (DXF) formats.




Figure 8.3.12. Example of the BESS MV-LV SLD.

8.3.13. Overhead line layout

The Overhead Line Layout shows the different blocks of towers, including the span and line lengths, distance between towers and elevation. The drawings are generated in both PDF and in CAD (DXF) formats.




Figure 8.3.13. Example of the Overhead Line Layout.